

Canada Communicable Disease Report

Date of Publication: December 1998 Volume 24S8

Supplement

# infection control guidelines

# Hand Washing, Cleaning, Disinfection and Sterilization in Health Care





Our mission is to help the people of Canada maintain and improve their health Health Canada

> This publication was produced by the Document Dissemination Division at the Laboratory Centre for Disease Control, Health Canada.

To obtain additional copies or subscribe to the Canada Communicable Disease Report, please contact the Member Service Centre, Canadian Medical Association, 1867 Alta Vista Drive, Ottawa, ON, Canada K1G 3Y6, Tel.: 888-855-2555 or by FAX: (613) 731-9102.

This publication can also be accessed electronically via Internet using a Web browser at http://www.hc-sc.gc.ca/hpb/lcdc

**Infection Control Guidelines** 

# Hand Washing, Cleaning, Disinfection and Sterilization in Health Care

Health Canada Laboratory Centre for Disease Control Bureau of Infectious Diseases Nosocomial and Occupational Infections

# **Introductory Statement**

The primary objective in developing clinical guidelines at the national level is to help health care professionals improve the quality of health care. Guidelines for the control of infection are needed to assist in developing policies, procedures and evaluative mechanisms to ensure an optimal level of care. Guidelines facilitate the setting of standards but respect the autonomy of each institution and recognize the governing body's authority and responsibility of ensuring the quality of patient/client care provided by the institution.

The guidelines, whenever possible, have been based on research findings. Where there is insufficient published research, consensus of experts in the field has been utilized to provide guidelines specific to conventional practice. The encouragement of research and frequent revision and updating are necessary if guidelines are to remain relevant and useful.

The Steering Committee acknowledges, with sincere appreciation, the many practising health professionals and others who contributed advice and information to this endeavour.

The guidelines outlined herein are part of a series that has been developed over a period of years under the guidance of the Steering Committee on Infection Control Guidelines. *Infection Control Guidelines for Hand Washing, Cleaning, Disinfection and Sterilization in Health Care* presents an overview and provides recommendations to assist in preventing the transmission of infection in health care facilities. This document is part of the Health Canada series of *Infection Control Guidelines* and is intended to be used with the other *Infection Control Guidelines*, which include the following:

Preventing the Transmission of Bloodborne Pathogens in Health Care and Public Services Settings (1997) *Isolation and Precaution Techniques* (1990) (under revision - to be published March, 1999)

Preventing the Spread of Vancomycin-Resistant Enterococci (1997)

Preventing the Transmission of Tuberculosis in Canadian Health Care Facilities and Other Institutional Settings (1996)

Canadian Contingency Plan for Viral Hemorrhagic Fevers and Other Related Diseases (1997)

Prevention of Infections Associated with Indwelling Intravascular Access Devices (1997)

Foot Care by Health Care Providers (1997)

*Occupational Health in Health Care Facilities* (1990) (under revision)

*Prevention of Nosocomial Pneumonia* (1990) (under revision)

Long Term Care Facilities (1994)

Antimicrobial Utilization in Health Care Facilities (1990)

Prevention of Surgical Wound Infections (1990)

Prevention of Urinary Tract Infections (1990)

Perinatal Care (1988)

Organization of Infection Control Programs in Health Care Facilities (1990) For information regarding these Health Canada publications, contact:

Division of Nosocomial and Occupational Infections Bureau of Infectious Diseases Laboratory Centre for Disease Control Health Canada, PL 0603E1 Ottawa, Ontario K1A 0L2 Telephone: (613) 952-9875 Fax: (613) 998-6413

# **Steering Committee on Infection Control Guidelines**

#### STEERING COMMITTEE MEMBERS

Dr. Lindsay Nicolle (**Chair**) H.E. Sellers Professor and Chair Department of Internal Medicine University of Manitoba Health Sciences Centre GC 430, 820 Sherbrooke Street Winnipeg, Manitoba R3A 1R9 Tel: (204) 787-7772 Fax: (204) 787-4826 e mail: nicolle@cc.umanitoba.ca

Dr. John Conly Hospital Epidemiologist and Associate Professor of Medicine The Toronto Hospital, Room 117A-NU13 200 Elizabeth Street Toronto, Ontario M5G 2C4 Tel: (416) 340-4858 Fax: (416) 340-5047 e mail: jconly@torhosp.toronto.on.ca

Dr. Charles Frenette Hôpital Charles Lemoyne 121 Taschereau Blvd. Greenfield Park, Qc J4V 2H1 Tel: (514) 466-5000 locale 2834 Fax: (514) 466-5778

Agnes Honish Manager, Communicable Disease Control Capital Health Authority Community and Public Health Suite 300, 10216 - 124th Street Edmonton, Alberta T5N 4A3 Tel: (403) 413-7944 Fax: (403) 413-7950

Dr. B. Lynn Johnston
Hospital Epidemiologist and Associate Professor of Medicine
Queen Elizabeth II Health Sciences Centre, Room 5-014 ACC
1278 Tower Road
Halifax, N.S.
B3H 2Y9
Tel: (902) 473-8477
Fax: (902) 473-7394

Linda Kingsbury Nurse Consultant Nosocomial and Occupational Infections Bureau of Infectious Diseases, Health Canada Laboratory Centre for Disease Control, 0603E1 Tunney's Pasture K1A 0L2 Tel: (613) 957-0328 Fax: (613) 998-6413 e mail: Linda\_Kingsbury@hc-sc.gc.ca

Louise Meunier Conseillère en prévention des infections Prévention des infections Hôpital Saint-Luc 1058 rue St. Denis Montréal, Québec H2X 3J4 Tel: (514) 281-3255, ext 5902 Fax: (514) 281-3293 Catherine Mindorff Community and Institutional Infection Prevention and Control 202 Yahara Place Ancaster, Ontario L9G 1Y5 Tel: (905) 304-1196 Fax: (905) 304-1999

Dr. Dorothy Moore Division of Infectious Diseases Montreal Children's Hospital 2300 Tupper Montréal, Québec H3H 1P3 Tel: (514) 934-4485 Fax: (514) 934-4494 e mail: dmooinf@mch.mcgill.ca

Laurie O'Neil Infection Prevention Consultant 4908 Nelson Rd. N.W. Calgary, Alberta T2K 2L9 Tel: (403) 282-2340

Shirley Paton Chief, Nosocomial and Occupational Infections Bureau of Infectious Diseases, Health Canada Laboratory Centre for Disease Control, 0603E1 Ottawa, Ontario K1A 0L2 Tel: (613) 957-0326 Fax: (613) 998-6413 e mail: Shirley\_Paton@hc-sc.gc.ca

Diane Phippen Epidemiologist Nurse Coordinator Cadham Provincial Laboratory Box 8450, 750 William Avenue Winnipeg, Manitoba R3C 3Y1 Tel: (204) 945-6685 (direct line) (204) 945-6123 (switchboard) Fax: (204) 786-4770

#### LIAISON REPRESENTATIVES

Association des médecins microbiologistes infectiologues du Québec (AMMIQ) Dr. Charles Frenette

Association pour la prévention des infections à l'hôpital et dans la communauté (APPI) Yolaine Rioux, Monique Delorme Canadian Association for Clinical Microbiology and Infectious Diseases (CACMID) Dr. Mary Vearncombe

Canadian Council on Health Services Accreditation Mrs. Marilyn Colton, Assist. Executive Director

Canadian Healthcare Association Rosa Paliotti, Barbara Lyons

Canadian Infectious Disease Society (CIDS) Dr. Gary Garber, Dr. John Conly

The Community and Hospital Infection Control Association - Canada (CHICA Canada) Deborah Norton, Clare Barry

#### **EX-OFFICIO MEMBER**

Dr. John Spika Director Bureau of Infectious Diseases Laboratory Centre for Disease Control, 0603E1 Health Canada Ottawa, Ontario K1A 0L2 Tel: (613) 957-4243 Fax: (613) 998-6413

### MEMBERS OF SUBCOMMITTEE ON HAND WASHING, CLEANING, DISINFECTION AND STERILIZATION IN HEALTH CARE

Agnes Honish (Chair) Manager, Communicable Disease Control Capital Health Authority Community and Public Health Suite 300, 10216 - 124 Street Edmonton, Alberta T5N 4A3 Tel: (403) 413-7944 Fax: (403) 413-7950

Dr. Gloria Delisle Director, Medical Microbiology Queen's University 116 Brock Street Kingston, Ontario K7L 5G2 Tel: (613) 544-3400 Fax: (613) 531-7953 Dr. Lynn Johnston
Hospital Epidemiologist and Associate Professor of Medicine
Queen Elizabeth II Health Sciences Centre, Room 5-014 ACC
1278 Tower Road
Halifax, Nova Scotia
B3H 2Y9
Tel: (902) 473-8477
Fax: (902) 473-7394

Linda Kingsbury Nurse Consultant Nosocomial and Occupational Infections Bureau of Infectious Diseases, Health Canada Laboratory Centre for Disease Control, 0603E1 Tunney's Pasture K1A 0L2 Tel: (613) 957-0328 Fax: (613) 998-6413 e mail: Linda\_Kingsbury@hc-sc.gc.ca

Susan Lafferty Infection Control Practitioner Royal Alexandra Hospital 10240 Kingsway Edmonton, Alberta T5H 3V9 Tel: (413) 491-5864 Fax: (403) 491-5886

Maureen Miller Infection Control Manager Caritas Health Group 1100 Youville Drive, West Edmonton, Alberta T6L 5X8 Tel: (413) 450-7308 Fax: (403) 450-7259

Pat Piaskowski Thunder Bay Regional Hospital 325 S. Archibald St. Thunder Bay, Ontario P7E 1G6 Tel: (807) 343-7123 Fax: (807) 343-7165 e mail: ppiaskow@microage-tb.com

Dr. Syed Sattar Professor of Microbiology and Director Centre for Research on Environmental Microbiology Faculty of Medicine University of Ottawa Ottawa, Ontario Tel: (613) 562-5800, ext. 8314 Fax: (613) 562-5452

Dr. Ann Skidmore Medical Microbiologist Surrey Memorial Hospital 13750 - 96th Avenue Surrey, British Columbia V3V 1Z2 Tel: (604) 581-2211 Fax: (604) 588-3322

The Steering Committee gratefully acknowledges the assistance of the Editorial and Production Unit, Document Dissemination Division, LCDC, Health Canada, and Translation Services, Montreal.

# **Table of Contents**

HAND	WASHI	<b>NG AND GLOVES</b>
A.	Microbio	plogy of the Skin
B.	Soaps an	nd Antiseptic Agents
C.	Waterles	ss Hand Scrubs
D.	Hand W	ashing Techniques
	Tab	le 1. Soaps and Antimicrobial Agents for Hand Washing
	Tab	le 2. Characteristics of Antiseptic Agents
E.	Complia	nce with Hand Washing Protocols
	Tab	le 3. How to Wash Hands
	Tab	le 4. Proposed Strategies to Improve Hand Washing Technique and Compliance 6
	Recomm	nendations on Hand Washing
F.	Gloves	
	i)	Glove use
	ii)	Selection of gloves
	iii)	Glove types
	iv)	Problems of glove use
	Recomm	nendations on Glove Use
CLEA	NING, D	<b>ISINFECTING AND STERILIZING PATIENT CARE EQUIPMENT</b>
		eation of Medical Devices
В.	Cleaning	g Equipment and Instruments
	Tab	le 5. Reprocessing of Commonly Used Equipment in Health Care Settings
		in Usual Situations
	i)	Sorting and soaking
	ii)	Removal of organic material
	iii)	Rinsing
	iv)	Drying

C.	Disinfect	ion
	i)	Chemical disinfection
	ii)	Relative resistance of microorganisms
	iii)	Creutzfeldt-Jakob disease (CJD)
	Figu	re 1. Classes of Microorganisms Ranked in Descending Order from
		Least to Most Susceptible to Chemical Disinfectants
	Tabl	e 6. Major Classes of Chemical Disinfectants and their Relative
		Advantages and Disadvantages
	Tabl	e 7. Directions for Preparing and Using Chlorine-based Disinfectants
	iv)	Reuse of chemical disinfectants
	v)	Disinfectants and safety
	vi)	Registration of disinfectants in Canada
	vii)	Product labelling
	viii)	Pasteurization
	ix)	Ultraviolet radiation
	x)	Boiling
	xi)	Sterilization
	xii)	New technologies
	xiii)	Monitoring of the sterilization cycle
	Tabl	e 8. Advantages and Disadvantages of Currently Available Sterilization Methods
	xiv)	Maintenance of sterility
		a. Packaging
		b. Storage
	Recomm	endations on Cleaning, Disinfection and Sterilization
Man		
MICR		GIC SAMPLING OF ENVIRONMENT
	Recomm	endations for Microbiologic Sampling
HOUS	EKEEPI	NG
		Cleaning
		e 9. Cleaning Procedures for Common Items
		endations for Routine Housekeeping
B.		Cleaning
	i)	Special organisms of epidemiologic significance
	ii)	Blood spills
		prime
	iii)	Surgical settings
		ommendations for Cleaning Surgical Settings

LAUNDRY	
Recomme	endations for Laundry
1.	Collection and handling
2.	Bagging and containment
3.	Transport
4.	Washing and drying
5.	Dry cleaning
6.	Sterile linen
7.	Protection of laundry workers
	GEMENT
	ealth Risk
	Recommendations for Management of Untreated Infectious Waste
B. Treatmen	t of Waste
i)	Chemical decontamination
ii)	Steam sterilization
C. Disposal	Methods for Waste
i)	Landfill
ii)	Sanitary sewer
iii)	Incineration
D. Safety for	Waste Handlers
Recomme	endations for Waste Management
REFERENCES	
Appendix 1.	Glossary
Appendix 2.	Guideline Rating System
Table 11.	Strength and Quality of Evidence for Recommendations
Appendix 3.	Drugs Directorate Guidelines

# Hand Washing and Gloves\*

Disease-causing microorganisms can frequently be isolated from the hands. Hand carriage of bacteria is an important route of transmission of infection between patients or from the health care worker to the patient/client<sup>(1-6)</sup>. Appropriate hand washing results in a reduced incidence of both nosocomial and community infections<sup>(1,7,8)</sup>. Guidelines from national and international infection prevention and control organizations have repeatedly acknowledged that **hand washing is the single most important procedure for preventing infections**<sup>(9-11)</sup>. Despite this, health care providers' compliance with hand washing is poor<sup>(12-14)</sup>.

This section will review the current literature on skin flora, antimicrobial agents used for hand antisepsis, hand washing techniques and other aspects of hand care and protection, and will make recommendations to be applied in the health care setting. Routine hand washing is discussed in this guideline, and the surgical hand scrub is discussed in *Infection Control Guidelines: Prevention of Surgical Wound Infections*<sup>(15)</sup>.

#### A. Microbiology of the Skin

Larson has provided an extensive review of the physiologic and bacteriologic characteristics of the skin<sup>(16)</sup>. The finger nail area is associated with a major portion of the hand flora. The subungual areas (located under the fingernail) often harbour high numbers of microorganisms, which may serve as a source of continued shedding, especially under gloves<sup>(17)</sup>.

Artificial nails<sup>(18)</sup> and chipped nail polish<sup>(19)</sup> may be associated with a further increase in the number of bacteria on fingernails.

The microbial flora of the skin consist of resident (colonizing) and transient (contaminating) microorganisms. The resident microorganisms survive and multiply on the skin. Resident flora include the coagulase-negative staphylococci, members of the genus *Corynebacterium* (diphtheroids or coryneforms), *Acinetobacter* species, and occasionally members of the Enterobacteriaceae group<sup>(20)</sup>. Resident skin microorganisms are not usually implicated in nosocomial infections, other than minor skin infections; however, some can cause infections after invasive procedures, when the patient/client is severely immunocompromised or has an implanted device, such as a heart valve or artificial hip.

The transient microbial flora represent recent contaminants of the hands acquired from colonized or infected patients/clients or contaminated environment or equipment. Transient microorganisms are not consistently isolated from most persons. In contrast to the resident flora, the transient microorganisms found on the hands of health care personnel are more frequently implicated as the source of nosocomial infections. The most common transient flora include gram negative coliforms and *Staphylococcus aureus*.

Hand washing with plain soap (detergents) is effective in removing most transient microbial flora<sup>(20-22)</sup>. **The components of good hand washing include using an adequate amount of soap, rubbing the hands together to create some friction, and rinsing under running water**. The mechanical action of washing, rinsing and drying removes most of the transient bacteria present<sup>(23-25)</sup>.

<sup>\*</sup> See Appendix 1 for definitions of the following terms: antimicrobial agent, antiseptic, hand wash(ing), hand antisepsis, heavy microbial soiling, plain or nonantimicrobial soap, sharps, surgical hand scrub.

In some studies, air dryers have been shown to reduce the number of organisms on hands after hand washing<sup>(26-28)</sup>. Several studies have demonstrated that air hand dryers are unsuitable for use in critical patient care areas because of the potential for cross infection, either through airborne dissemination or contaminated personnel<sup>(24,29-31)</sup>. Air dryers may be an impediment to hand drying because of the time taken to dry hands and the need to ensure that the equipment is functioning.

### **B.** Soaps and Antiseptic Agents

The purpose of hand washing is to remove soil, organic material and transient microorganisms from the skin. Few clinical studies have defined the absolute indications for hand washing with plain soaps (detergents) versus hand antisepsis with antimicrobial products. Controlled trials have not documented decreased infection with the use of an antiseptic agent over plain soap for routine hand washing in the general health care setting. The degree of reduction in microbial numbers on the hands of health care providers necessary to protect the recipient of care has not been defined. A few studies have suggested that antiseptic agents may be preferable for the care of patients if there is a possibility of antimicrobial-resistant organisms, such as in intensive care units<sup>(3,32)</sup>, in the presence of antimicrobial-resistant organisms<sup>(33-36)</sup>, and under conditions of heavy microbial soiling (e.g., in the presence of infection or a high level of contamination with organic matter such as feces)<sup>(37)</sup>.

Understanding the distinctive ingredients and uses of the soap and antiseptic products available is important in choosing the appropriate agent for the appropriate situation. If an antiseptic product is used, it should be selected for its chemical composition, its type and spectrum of activity, its onset and duration of activity, the application for which it will be used, its cost, allergenic potential and acceptability to the users. Whatever product is used, it should be applied at the right dilution for the recommended time with standard methods of application.

Antiseptic hand cleansers are designed to rapidly wash off the majority of the transient flora by their mechanical detergent effect and to exert an additional sustained antimicrobial activity on the resident hand flora (Tables 1 and 2)<sup>(38,39)</sup>.

#### **C. Waterless Hand Scrubs**

Several studies have demonstrated superior efficacy of waterless hand scrubs compared with hand washing with

soap and water or chlorhexidine<sup>(36,47-50)</sup>. Alcohol-based compounds for hand antisepsis predominate in several European countries<sup>(51-53)</sup>. Alcohol preparations offer rapid reduction in microbial counts on skin<sup>(54)</sup>: a vigorous, 1-minute rubbing with enough alcohol to wet the hands completely has been shown to be an effective method of hand antisepsis<sup>(20,36,51,55,56)</sup>. Alcohol applications as short as 15 seconds in duration have been effective in preventing hand transmission of gramnegative bacteria<sup>(37,57)</sup>. The advantages of alcohol rubs include the following: (1) they have an immediate and delayed antimicrobial performance, (2) no wash basin is necessary for their use and (3) alcohol rubs can be conveniently available near every patient/client and are more practical when there is insufficient time to wash hands<sup>(42,57,58)</sup>. Alcohol preparations are useful in home care when proper facilities for hand washing may be lacking<sup>(59)</sup>.

A major disadvantage of alcohol for skin antisepsis is its effect on the user. Waterless hand scrubs may have a drying effect on the skin of the hands, and product odours may be irritating for health care workers. The addition of emollients to minimize skin drying increases the acceptability of alcohol-based solutions on the hands<sup>(55)</sup>. The antimicrobial efficacy of alcohols is sensitive to dilution with water, therefore alcohol preparations must be rubbed onto dry hands<sup>(55)</sup>. The activity of alcohol does not appear to be significantly affected by small amounts of blood<sup>(60)</sup>; however, further studies are needed to determine activity in the presence of large amounts of organic matter.

See Table 2 for a description of the antimicrobial activity and uses of antiseptic agents.

#### **D. Hand Washing Techniques**

The absolute indications for and the ideal frequency of hand washing have not been well studied. The indications for hand washing depend on

- (a) the type, intensity, duration and sequence of activity;
- (b) the degree of contamination associated with the contact; and
- (c) the susceptibility to infection of the health care recipient.

Product	Indications	Special considerations		
Plain soap, bar soap, liquid*, granules	For routine care of patients/residents/clients <sup>(10,20,40)</sup> For washing hands soiled with dirt, blood or other organic	May contain very low concentrations of antimicrobial agents to prevent microbial contamination growth in the product.		
	material	Bar soap should be on racks that allow water to drain; small bars that can be changed frequently are safest <sup><math>(11,41)</math></sup> .		
Waterless antiseptic agents:	Demonstrated alternative to conventional agents <sup>(42)</sup>	Not effective if hands are soiled with dirt or heavily contaminated		
- rinses	For use where hand washing facilities are inadequate,	with blood or other organic material.		
- foams	impractical or inaccessible (e.g., ambulances, home care, mass	Follow manufacturer's recommendations for use.		
- wipes	immunization)	Efficacy affected by concentration of alcohol in product.		
- towelettes	For situations in which the water supply is interrupted (e.g., planned disruptions, natural disasters)	Hand creams should be readily available to protect skin integrity <sup>(43-45)</sup> .		
Antiseptic agents	Refer to recommendations at end of this chapter.	Antiseptic agents may be chosen if it is felt important to reduce the		
	May be chosen for hand scrubs prior to performance of invasive procedures (e.g., placing intravascular lines or devices) <sup>(34)</sup> .	number of resident flora or when the level of microbial contamination is high.		
	When caring for severely immunocompromised individuals	Antiseptic agents should be chosen when persistent antimicrobial activity on the hands is desired.		
	Based on risk of transmission (e.g., specific microorganisms)	They are usually available in liquid formulations*.		
	Critical care areas	Antiseptic agents differ in activity and characteristics <sup>(38,39)</sup> .		
	Intensive care nurseries			
	Operating room scrub	Routine use of hexachlorophene is not recommended because of neurotoxicity and potential absorption through the skin <sup>(46)</sup> .		
	When caring for individuals with antimicrobial resistant organisms <sup>(33)</sup>	Alcohol containers should be stored in areas approved for flammable materials.		

\* Disposable containers are preferred for liquid products. Reusable containers should be thoroughly washed and dried before refilling, and routine maintenance schedules should be followed and documented. Liquid products should be stored in closed containers and should not be topped-up.

# Table 2. Characteristics of Antiseptic Agents

Group and subgroup	Gram-positive bacteria	Gram-negative bacteria	Mycobacterium tuberculosis	Fungi	Virus	Speed of killing sensitive bacteria	Inactivated by mucus or proteins	Comments
Alcohols	Good	Good	Good	Good	Good	Fast	Moderate	Optimum strength 70% to 90% with added emollients (glycerine or cetyl alcohol is less drying), not recommended for physical cleaning of skin; good for hand antisepsis and for surgical site preparation.
Chlorhexidine 2% and 4% aqueous	Good	Good	Fair	Fair	Good	Intermediate	Minimal	Has persistent effect; good for both hand washing and surgical site or preoperative patient skin preparation; do not use near mucous membranes; toxic effects on ears and eyes reported; activity neutralized by nonionic surfactants.
Hexachloro- phene 3% aqueous	Good	Poor	Poor	Poor	Poor	Slow	Minimal	Provides persistent, cumulative activity after repeated use (washing with alcohol reduces persistent action), can be toxic when absorbed from skin especially in premature infants; good for hand washing but not for surgical site preparation; limited spectrum of antimicrobial activity.
Iodine compounds, iodine in alcohol	Good	Good	Good	Good	Good	Fast	Marked	Causes skin "burns," but this is unusual with 1% tincture, especially if it is removed after several minutes; too irritating for hand washing but excellent for surgical site preparation.
Iodophors	Good	Good	Fair	Good	Good	Intermediate	Moderate	Less irritating to the skin than iodine; good for both hand washing and surgical site preparation; rapidly neutralized in presence of organic materials such as blood or sputum
Para-chloro- meta-xylenol (PCMX)	Good	Fair*	Fair	Fair	Fair	Intermediate	Minimal	Activity neutralized by nonionic surfactants
Triclosan	Good	Good	Fair	Poor	Good	Intermediate	Minimal	

\*Activity improved by addition of chelating agent such as EDTA. Note: Some of these agents, such as iodine or chlorhexidine, are combined with alcohol to form tinctures and are available in the combined formulation<sup>(10)</sup>. Table used with permission of author and publisher<sup>(10)</sup>.

### Table 3. How to Wash Hands

Procedure	Rationale
Remove jewelry before hand wash procedure <sup>(38,61)</sup> .	
Rinse hands under warm running water.	This allows for suspension and washing away of the loosened microorganisms.
Lather with soap and, using friction, cover all surfaces of the hands and fingers.	The minimum duration for this step is 10 seconds <sup>(25)</sup> ; more time may be required if hands are visibly soiled.
	For antiseptic agents 3-5 mL are required <sup>(38)</sup> .
	Frequently missed areas are thumbs, under nails, backs of fingers and hands.
Rinse under warm running water.	To wash off microorganisms and residual hand washing agent
Dry hands thoroughly with single-use towel or forced air dryer.	Drying achieves a further reduction in number of microorganisms <sup>(24,29,38)</sup> .
	Reusable towels are avoided because of the potential for microbial contamination.
Turn off faucet without recontaminating hands.	To avoid recontaminating hands.
Do not use fingernail polish or artificial nails.	Artificial nails or chipped nail polish may increase bacterial load and impede visualization of soil under nails <sup>(18,62)</sup> .

The efficacy of a hand wash depends on the time taken and the technique. The recommended hand washing technique is outlined in Table 3. It is important to avoid potential microbial contamination by splashing of clothing, other skin surfaces or inanimate items during hand washing.

#### **E.** Compliance with Hand Washing Protocols

Although hand washing is considered the most important single intervention for preventing nosocomial infections<sup>(1-6)</sup>, studies have repeatedly shown poor compliance with hand washing protocols by hospital personnel<sup>(3,12,13,63,64)</sup>. Failure to comply is a complex problem that includes elements of lack of motivation and lack of knowledge about the importance of hand washing. It may also be due to real or perceived obstacles, such as understaffing, inconveniently located hand washing facilities, an unacceptable hand washing product or dermatitis caused by previous hand washing. A number of strategies have been suggested to improve compliance (Table 4). Long-term success will require development of programs and sustained efforts at promoting compliance with hand washing. Effective interventions will probably be multidimensional, and will require the application of behavioural science theory combined with engineering and/or product innovation<sup>(7,8)</sup>.

### Table 4. Proposed Strategies to Improve Hand Washing Technique and Compliance

Obstacle	Strategy		
Lack of knowledge	Education with supportive literature, videotaped instructions, hand washing demonstrations; frequent refreshers; involvement of personnel in education and feedback <sup>(7,8,65)</sup>		
	Feedback on infection rates <sup>(64)</sup>		
Lack of motivation	Direct observation and feedback on regular basis <sup>(65)</sup> ; role models; involvement of staff in studies; application of new technologies <sup>(63,66-69)</sup>		
	Programs on hand hygiene for patients and families <sup>(64,70)</sup>		
Availability of hand washing facilities	Hand washing facilities conveniently located throughout the health care setting <sup>(67,68)</sup>		
	A sink accessible to personnel in or just outside every room; more than one sink per room may be necessary if a large room is used for several individuals.		
	Hand washing facilities in or adjacent to rooms where health care procedures are performed		
	Accessible, adequately supplied and proper functioning soap and towel dispensers or hand dryers		
	Faucets with foot, wrist or knee operated handles; faucets with an electric eye are also desirable.		
	Waterless antiseptic agents readily available in wall mounted dispensers, or in small containers for mobile care such as home care and for emergency responders.		
Hand washing product	Hand washing products that have a high level of acceptability to staff, with appropriateness, cost, supply, etc., being taken into consideration <sup>(55,59)</sup>		
Dermatitis	Lotions to prevent skin dryness		
	Lotion supplied in small, non-refillable containers <sup>(43-45,72)</sup>		
	Compatibility between lotion and antiseptic products and effect on glove integrity		
	Lotions approved by personnel in infection control and occupational health <sup>(73)</sup>		

### **Recommendations on Hand Washing**

- 1. Hands must be washed
  - (i) between direct contact with individual patients/residents/clients;
  - (ii) before performing invasive procedures<sup>(11,20)</sup>;
  - (iii) before caring for patients in intensive care units and immunocompromised patients<sup>(11,20)</sup>;
  - (iv) before preparing, handling, serving or eating food, and before feeding a patient;

- (v) when hands are visibly soiled  $^{(13,20)}$ ;
- (vi) after situations or procedures in which microbial or blood contamination of hands is likely;
- (vii) after removing gloves  $^{(11,20,74)}$ ; and
- (viii) after personal body functions, such as using the toilet or blowing one's nose. Category B; Grade II\*
- 2. Hand washing should be encouraged whenever a health care provider is in doubt about the necessity for doing so. **Category B; Grade III**

<sup>\*</sup> See Appendix 2 for the rating system used in these recommendations.

- 3. As well as between patient/resident/client contacts, hand washing may be indicated more than once in the care of one person, for example after touching excretions or secretions and before going on to another care activity for the same person<sup>(37)</sup>. **Category B; Grade II**
- 4. Superficial contact with an object not suspected of being contaminated, such as when touching or collecting food trays, generally does not require hand washing. **Category B; Grade III**
- 5. Hand washing facilities should be conveniently located throughout the health care setting. They should be available in or adjacent to rooms where health care procedures are performed. If a large room is used for several individuals, more than one sink may be necessary. Sinks for hand washing should be used only for hand washing and not for any other purpose, e.g., as a utility sink. There should be access to adequate supplies and proper functioning soap and towel dispensers or hand dryers, or liberal use of waterless hand wash agents<sup>(41,68,69)</sup>. Category B; Grade II
- 6. To avoid recontaminating hands, faucets with foot, wrist, or knee operated handles should be installed wherever possible; faucets with an electric eye are also desirable. If automated faucets are not available, single-use towels should be supplied for user to turn off faucets. **Category B; Grade III**
- Hands should be dried thoroughly with either a single-use towel or electric air dryer<sup>(26,27)</sup>. Category A; Grade II
- Hand lotion may be used to prevent skin damage from frequent hand washing<sup>(55)</sup>. Lotion should be supplied in disposable bags in wall containers by sinks or in small, non-refillable containers to avoid product contamination. Skin lotions for patient and/or staff use have been the reported source of outbreaks<sup>(43-45,72,73)</sup>. Category B; Grade II
- 9. Compatibility between lotion and antiseptic products and lotion's potential effect on glove integrity should be checked<sup>(75,76)</sup>. **Category A; Grade II**
- Liquid hand wash products should be stored in closed containers and dispensed from either disposable containers or containers that are washed and dried thoroughly before refilling. Category A; Grade II

- Hand washing with plain soap is indicated in routine health care and for washing hands soiled with dirt, blood or other organic material. Plain soap and water will remove many transient organisms<sup>(20-22,40,59,77)</sup>.
   Category A; Grade II
- 12. Hand washing with an antiseptic agent is indicated for the following situations:
  - (i) when there is heavy microbial soiling, e.g., in the presence of infection or a high level of contamination with organic matter such as infected wounds and feces<sup>(36,47,48,78)</sup>. Category A; Grade II;
  - (ii) prior to performing invasive procedures (e.g., the placement and care of intravascular catheters, indwelling urinary catheters)<sup>(2,5,6)</sup>.
     Category A; Grade I;
  - (iii) before contact with patients who have immune defects, damage to the integumentary system (e.g., wounds, burns), or percutaneous implanted devices<sup>(3,6)</sup>. Category A; Grade II;
  - (iv) before and after direct contact with patients who have antimicrobial-resistant organisms<sup>(32,35,36)</sup>. Category A; Grade II
- 13. Hand washing with waterless/alcohol-based agents is equivalent to soap and water, and these agents should be made available where access to water is limited<sup>(42,59,78)</sup>. If there is heavy microbial soiling, hands must first be washed with soap and water to remove visible soiling<sup>(20)</sup>. Hands must be dry before an alcohol-based agent is used because moisture from wet hands dilutes the alcohol. **Category A; Grade II**
- 14. Compliance with hand washing procedures should be encouraged by involving users as much as possible in product selection, facilities design, studies, application of new technologies, education programs and feedback<sup>(63,64,69)</sup>. **Category A; Grade II**
- 15. Patients/clients/residents in settings where patient hygiene is poor should have their hands washed. Patients/residents should be helped to wash their hands before meals, after going to the bathroom, before and after dialysis, and before leaving their room. **Category B; Grade III**

### F. Gloves

### i) Glove use

- Gloves are worn to
- a. provide an additional protective barrier between health care workers' hands and blood, body fluids, secretions, excretions and mucous membranes<sup>(74,79)</sup>, and
- b. reduce the potential transfer of microorganisms from infected patients to health care workers, and from patient to patient via health care workers' hands<sup>(81)</sup>.

Glove use should be an adjunct to, not a substitution for, hand washing. If hand washing is performed carefully and appropriately by all personnel, gloves are not necessary to prevent transient colonization of health care workers' hands and subsequent transmission to others<sup>(82)</sup>.

In 1987, the Laboratory Centre for Disease Control (LCDC) recommended the use of gloves for specific situations, primarily to protect the health care worker from exposure to bloodborne pathogens<sup>(83)</sup>. Application of universal precautions<sup>(82-84)</sup> significantly increased the use of gloves in the health care setting. Some institutions adopted body substance isolation precautions<sup>(85)</sup>, which expanded the use of gloves to prevent contamination of hands.

#### ii) Selection of gloves

It is important to assess and select the most appropriate glove to be worn for the circumstances. Selection of gloves should be based on a risk analysis of the type of setting, type of procedure, likelihood of exposure to blood or fluid capable of transmitting pathogens, length of use and amount of stress on the glove<sup>(86)</sup>. Factors such as personal comfort and fit, cost and latex allergy in employees and clients/residents are also important considerations.

#### iii) Glove types

Non-sterile gloves sold in Canada must meet the requirements of Health Canada Information Letter No. 777 (April 30, 1990). Health Canada recommends purchasing gloves with the Canadian General Standards Board certification mark, which ensures that voluntary national standards are met during manufacturing. However some types of glove materials are not available in certified brands. The Medical Devices Bureau of Health Canada has an information package on glove quality and certification, and on latex allergy (1-800-267-9675)<sup>(87)</sup>.

Studies have demonstrated varying effectiveness of gloves as barrier protection. Some studies have concluded that latex gloves were associated with less leakage than vinyl gloves<sup>(74,88-92)</sup>. Other studies have shown non-latex gloves to be effective<sup>(79,93-96)</sup>.

#### iv) Problems of glove use

Constant use of gloves may cause irritant dermatitis. The cause of the dermatitis may be mechanical irritation from the glove or glove powder; it may also be chemical agents, such as residual soap, trapped between the glove and skin.

Latex allergy is an increasing concern in health care settings because of the potentially serious outcomes in workers and clients who are allergic to latex. Some employees affected by latex allergy may be able to work in an area where others are using low protein, nonpowdered latex gloves. Employees and clients who are severely allergic to latex need to avoid all contact with it.

For further information on latex allergy in health care facilities, refer to the Canadian Healthcare Association publication *Guidelines for the Management of Latex Allergy and Safe Latex Use in Health Care Facilities*<sup>(97)</sup>.

#### **Recommendations on Glove Use**

For further information and recommendations on glove use, refer to Health Canada's *Infection Control Guidelines Preventing the Transmission of Bloodborne Pathogens in Health Care and Public Services Settings*<sup>(84)</sup> and the revision of Health Canada's *Isolation and Precaution Techniques*<sup>(98)</sup>.

- Gloves should be used as an additional measure, not as a substitute for hand washing<sup>(74,99)</sup>. Category B: Grade II
- Gloves are not required for routine patient care activities if contact is limited to a patient's intact skin, e.g., when transporting patients. Category B; Grade III
- 3. Gloves may not be needed for routine diaper changes if the procedure can be done without contaminating the hands with stool or urine. **Category C**
- 4. Clean non-sterile gloves should be worn
  - (i) if exposure is anticipated to blood and body fluids capable of transmitting bloodborne infection<sup>(84)</sup>,
  - (ii) if exposure is anticipated to potentially infectious material such as pus, feces,

respiratory secretions or exudate of skin lesions<sup>(81,85)</sup>,

- (iii) when the health care worker has non-intact skin on his or her hands. **Category A; Grade II**
- Sterile gloves must be worn for procedures in which the hands or the instruments being handled are entering a sterile body cavity or tissue<sup>(2,100)</sup>.
   Category A; Grade I
- 6. The accepted standard should be that medical gloves be worn for all blood collection procedures. However, if phlebotomists choose not to wear gloves routinely, they must be gloved for perfoming phlebotomy if they have cuts, scratches or other breaks in their skin, or when hand contamination with blood is anticipated. All students or new trainees must wear medical gloves during their training period and in subsequent blood collection procedures<sup>(84)</sup>.
- 7. Worn gloves should be changed
  - (i) between patient/client/resident contacts,
  - (ii) if a leak is suspected or the glove tears,
  - (iii) between care activities and procedures on the same patient after contact with materials that may contain high concentrations of microorganisms (e.g., after manipulating an indwelling urinary catheter and before suctioning an endotrachial tube)<sup>(74,88).</sup>
     Category A; Grade II
- 8. Hands must be washed after gloves are removed<sup>(74,86,89,91)</sup>. **Category A; Grade II**

- Potentially contaminated gloves should be removed prior to touching clean environmental surfaces (e.g., lamps, blood pressure cuffs)<sup>(74,101)</sup>. Category A; Grade II
- 10. Single-use disposable gloves should not be washed or reused. Category A; Grade II
- 11. Disposable, good quality medical gloves made of vinyl, nitrile, neoprene or polyethylene serve as adequate barriers, particulary when latex allergies are a concern. **Category A; Grade II**

The *Health and Safety Act* requires that employers provide appropriate personal protective apparatus<sup>(102)</sup>. They should make suitable gloves available to employees to prevent the transmission of infection to residents/clients/patients. Employees should assess the risk in each procedure, choose gloves that are appropriate to the task, and recommend alternative gloves if the ones available are not adequate<sup>(84,86)</sup>. The following is suggested as a guide.

- (i) If latex gloves are chosen, low protein and unpowdered gloves should be selected.
- (ii) Non-latex gloves should be available for individuals with latex sensitivity.
- (iii) Vinyl gloves should be used for short tasks or for tasks in which there is minimal stress to glove material.
- (iv) For housekeeping activities, instrument cleaning and decontamination procedures, general purpose reusable household gloves (e.g., neoprene, rubber, butyl) are recommended. Medical gloves are not durable enough for these activities.

# Cleaning, Disinfecting and Sterilizing Patient Care Equipment\*

Appropriate cleaning, disinfection and sterilization of patient care equipment are important in limiting the transmission of organisms related to reusable patient care equipment. Decisions concerning the appropriate processes, methods or products are complex, given the many types and compositions of medical devices and the great variety and combination of cleaning, disinfection and sterilization methods available<sup>(103-108)</sup>.

The reprocessing method required for a specific item will depend on the item's intended use, the risk of infection to the patient, and the amount of soiling<sup>(59,109-111)</sup>. **Cleaning is always essential prior to disinfection or sterilization. An item that has not been cleaned cannot be assuredly disinfected or sterilized.** See Table 5 for examples.

#### A. Classification of Medical Devices

In the 1970s, E.H. Spaulding developed a system to classify the cleaning, disinfection and sterilization requirements for equipment used in patient/client care. This system divides medical devices, equipment and surgical materials into three categories based on the potential risk of infection involved in their use<sup>(117)</sup>. The three categories are noncritical, semicritical, and critical. The categories are defined in the glossary at the end of this document.

### **B.** Cleaning Equipment and Instruments

Cleaning is an extremely important part of equipment and instrument reprocessing and is

# necessary to permit maximum efficacy of subsequent disinfection and sterilization treatments.

Effective cleaning can physically remove large numbers of microorganisms<sup>(118)</sup>. Soil or other foreign materials can shield microorganisms and protect them from the action of disinfectants or sterilants or interact with the disinfectant or sterilant to neutralize the activity of the process<sup>(119-122)</sup>. Organic material left on a medical device is extremely difficult to remove after treatment with glutaraldehyde, which acts as a fixative.

Manufacturers must provide detailed directions for effective cleaning of all reusable products. The method and effectiveness of cleaning an item must be considered prior to purchase. Do not purchase products that cannot be cleaned. If such products are purchased the health care setting has the responsibility to develop detailed cleaning procedures. Effective reprocessing requires rigorous compliance with recommended protocols. Even full compliance with protocols may be insufficient if the method or product selected is inadequate or inappropriate for cleaning and subsequent disinfection or sterilization of a particular device.

Staff responsible for cleaning contaminated health care equipment must be properly trained and conversant with the purpose of their task. They should wear personal protective equipment appropriate to the task to protect themselves from exposure to potential pathogens and chemicals and to protect the integrity of their skin. Employees should also be immunized against hepatitis B<sup>(84)</sup>.

<sup>\*</sup> See Appendix 1 for definitions of the following items: noncritical items, semicritical items, critical items, biofilm, cleaning, decontamination, disinfection, germicides, low level disinfection, intermediate level disinfection, high level disinfection, sanitation, sterilization.

Table 5. Reprocessing of Commonly Used Equipment in Health Care Settings in Usual Situations (See the section on Housekeeping for routine environmental cleaning; outbreaks may require special disinfection measures)

Process	Equipment	Examples of items*	Products or methods†
<b>Cleaning</b> Some items may require low level <b>disinfection</b> <sup>‡</sup>	All reusable equipment	All reusable equipment, since such equipment requires cleaning after use and before further disinfection processes are initiated	Physical removal of soil, dust or foreign material. Chemical, thermal or mechanical aids may be used. Cleaning usually involves soap and water,
		Certain environmental surfaces (e.g., of dental lamps) touched by personnel during procedures involving parenteral or mucous membrane contact Bedpans, urinals, commodes Stethoscopes Blood pressure cuffs Ear specula Hemodialysis surfaces in contact with	detergents or enzymatic agents. Quaternary ammonium compounds Phenolics should not be used in nurseries Some iodophors 3% hydrogen peroxide
		dialysate	
<b>Cleaning</b> followed by intermediate level <b>disinfection</b> <sup>‡</sup>	Some semicritical items	After large environmental blood spills or spills of microbial cultures in the laboratory Glass thermometers Electronic thermometers Hydrotherapy tanks used for patients whose skin is not intact <sup>‡</sup>	Alcohols Hypochlorite solutions Iodophors Phenolics should not be used in nurseries.
<b>Cleaning</b> followed by high level <b>disinfection</b>	Semicritical items	Flexible endoscopes <sup>‡</sup> Laryngoscopes <sup>‡</sup> Respiratory therapy equipmenta <sup>‡</sup> Nebulizer cups <sup>‡</sup> Anesthesia equipment <sup>‡</sup> Endotrachial tubes <sup>‡</sup> Nasal specula Tonometer foot plate <sup>‡</sup> Ear syringe nozzles Vaginal specula Vaginal probes used in sonographic scanning <sup>‡</sup> Pessary and diaphragm fitting rings <sup>‡</sup> Cervical caps Breast pump accessories	Items intended for sterilization in the plasma or EO sterilizers must be meticulously cleaned prior to sterilizing <sup>(112)</sup> . Pasteurization <sup>(113)</sup> 2% glutaraldehyde 6% hydrogen peroxide Peracetic acid Chlorine or chlorine compounds

MANUFACTURERS' RECOMMENDATIONS FOR CONCENTRATION AND EXPOSURE TIME MUST BE FOLLOWED.

<sup>\*</sup> For products that appear in two categories, manufacturers' directions differ for length of exposure time and concentration.

<sup>&</sup>lt;sup>†</sup> Manufacturers' recommendations for concentration and exposure time must be followed.

<sup>&</sup>lt;sup>‡</sup> For guidelines regarding disinfection, refer to comprehensive discussion of disinfection issues<sup>(110,114-116)</sup>.

Process	Equipment	Examples of items*	Products or methods†
Cleaning	Critical items	All items contacting sterile tissue	Steam under pressure
followed by		Surgical instruments	Dry heat
sterilization		All implantable devices	Ethylene oxide gas
		Needles and syringes	2% glutaraldehyde
		Cardiac and urinary catheters	6-25 % hydrogen peroxide
		Hemodialysis, plasmapheresis and heart-lung	Peracetic acid
		oxygenator surfaces in contact with blood	Chlorine dioxide
		All intravascular devices	6-8% formaldehyde
		Biopsy forceps or biopsy equipment associated with endoscopy equipment	
		Bronchoscopes <sup>‡</sup>	
		Arthroscopes <sup>‡</sup>	
		Laparoscopes <sup>‡</sup>	
		Cystoscopes <sup>‡</sup>	
		Transfer forceps	
		Acupuncture needles and body piercing objects	
		Neurologic test needles	
		Arterial pressure transducers <sup>‡</sup>	
		High speed dental handpieces	
		All instruments used for footcare	

For products that appear in two categories, manufacturers' directions differ for length of exposure time and concentration.

Manufacturers' recommendations for concentration and exposure time must be followed.

<sup>‡</sup> For guidelines regarding disinfection, refer to comprehensive discussion of disinfection issues<sup>(110,114-116)</sup>.

#### i) Sorting and soaking

Unless they can be cleaned immediately, instruments and small items should be sorted and then submerged in water and/or detergent to prevent the organic matter from drying on them. Complete disassembly of each item is necessary to allow effective cleaning. Heavy or nonimmersible items should be wrapped in or covered with a wet towel.

#### ii) Removal of organic material

Removal is done with the use of detergents, enzymatic cleaners, or elevated temperature with or without the use of mechanical devices such as washer-sterilizer, ultrasonic cleaner, dishwasher, utensil washer or washerdisinfectors. A detergent is used to reduce surface tension and suspend the soil in water. The detergent selected must be compatible with the subsequent disinfection process because some products can interfere with chemical disinfection or sterilization. An enzymatic solution may be used to help in the removal of proteinaceous material when plain water and/or a detergent solution is considered inadequate. Combination low level disinfectant-detergent products (also referred to as germicidal detergents) are frequently used to clean items that do not require further disinfection or sterilization (e.g., intravenous [IV] poles, commodes, wheelchairs).

#### iii) Rinsing

A thorough rinsing is necessary to remove all the soil and cleaning agent from the items, to avoid spotting and to ensure thorough cleanliness. Depending upon the quality of the available water supply, the final rinse may require distilled or de-ionized water<sup>(119)</sup>. Cleaning agents (i.e., detergents) may also make surfaces slippery or leave residuals that impair equipment integrity and function. When cleaning is to be followed by disinfection, it must be ensured that residuals of the cleaning agent are removed to prevent neutralization of the disinfectant<sup>(120,123)</sup>.

#### iv) Drying

Drying prevents microbial growth. All items that require no further treatment must be dried prior to storage. Immediate drying is necessary to prevent corrosion of stainless steel equipment. While they are drying, the items should be inspected to ensure that they are free of all organic soil, oil, grease, and other matter<sup>(124)</sup>. Post-disinfection flushing of endoscopes with 70% alcohol to ensure thorough drying prior to storage has been recommended<sup>(118)</sup>.

Bacteria grow attached to surfaces because of their hydrophobicity (insolubility in water)<sup>(119,125)</sup>. When nonsterile surfaces are moist or continuously wet, they may become coated with a "biofilm", which is a layer of bacteria encased in an extracellular substance. Biofilm and its bacteria can be released when disrupted (e.g., in the lumens of endoscopes). Biofilm development may also protect bacteria from subsequent disinfection or sterilization.

Items that require further disinfection or sterilization may also need to be dried, as water may dilute the action of the chemical disinfectant.

#### **C. Disinfection**

Disinfection is required when cleaning processes alone do not render an item safe for its intended use. There are three major methods of disinfection: liquid chemicals, pasteurization and ultraviolet radiation. Failure to use disinfection products or processes appropriately has repeatedly been associated with the transmission of nosocomial infections<sup>(117,126, 127)</sup>. Table 5 shows the cleaning and disinfection levels required for many commonly used items of equipment.

In health care settings, the precise nature of the microbial burden may not be known. In the natural environment, microorganisms are usually found in mixtures. For example, fecal material contains vegetative as well as spore forms of bacteria along with fungi, viruses and protozoa. Therefore, products and procedures selected to disinfect instruments must be known to be effective against pathogens with varying levels of resistance (See Figure 1). The level of disinfection achieved depends on factors such as contact time, temperature, extent of soil, type and concentration of the active ingredients of the chemical disinfectant, and the nature of the microbial contamination<sup>(121,126,128)</sup>.

A variety of factors influence the efficacy of disinfectant processes, including the innate resistance of the microorganisms (Figure 1), the concentration and type of organic and inorganic material present (cleanliness, presence of biofilm), the intensity and duration of the treatment, the concentration (on initial and repeated use) of the disinfectant, the temperature associated with the process, the contact time associated with the process, the pH of the solution, the hardness of water used as the diluent, and interfering residues that may remain after cleaning<sup>(126,128, 129)</sup>.

#### i) Chemical disinfection

In Canada, chemical disinfectants used in health care settings are regulated by the Health Protection Branch of Health Canada (see the discussion of Registration of Disinfectants in Canada later in this section).

#### ii) Relative resistance of microorganisms

Microorganisms have variable susceptibility to disinfectant agents (see Figure 1). Vegetative bacteria and enveloped viruses are usually the most sensitive, and bacterial spores and protozoan cysts the most resistant. Some pathogens (e.g., *Pseudomonas aeruginosa*) have been shown to be significantly more resistant than their laboratory grown counterparts to a variety of disinfectants in their "naturally occurring" state, (i.e., in body fluids and tissues)<sup>(110)</sup>.

Major classes of disinfectant chemicals and their relative advantages and disadvantages are summarized in Table 6. The manufacturer of the chemical disinfectant will provide instructions for use, including the recommended exposure time. Manufacturers' recommendations regarding exposure time must be followed.

#### iii) Creutzfeldt-Jakob Disease (CJD)

The Laboratory Centre for Disease Control is developing CJD protocols<sup>(134,135)</sup>. The prion that causes Creutzfeldt-Jakob resists normal inactivation methods. Human infection with the CJD agent has resulted from either direct exposure of the brain to the CJD agent (e.g., dura mater graft) or peripheral injection of CJD agentcontaminated product derived from human brain (pituitary hormone). Special CJD-specific infection control precautions are recommended for patients who have developed, are suspected of having developed, or are at substantially increased risk of developing CJD (i.e., persons who have received human pituitary hormone [growth hormone and gonadotrophin] or dura mater grafts, or members of a family in which CJD is recognized as being familial)<sup>(135)</sup>.

Needles, needle electrodes, scalpels, ophthalmic tonometers, autopsy instruments, dedicated equipment cryostats and all other potentially contaminated materials should be sterilized by special procedures. 14

# Figure 1.

Classes of Microorganisms Ranked in Descending Order from Least to Most Susceptible to Chemical Disinfectants

Least susceptible	BACTERIA WITH SPORES (Bacillus subtilis, Clostridium teta C. botulinum) PROTOZOA WITH CYSTS (Giardia lamblia, Cryptosporidium		Chemical Sterilant			
	MYCOBACTERIA (Mycobacterium tuberculosis M. avium-intracellulare, M. chelonae)	NON-ENVELOPED VIRUSES (Coxsackieviruses, polioviruses, rhinoviruses, rotaviruses, Norwalk virus, hepatitis A virus)	R.	High Level		
	FUNGI (Candida species, Cryptococcus species, A	Aspergillus species, Dermatophytes)		Disinfection	Intermediate	
Most susceptible	VEGETATIVE BACTERIA (Staphylococcus aureus, Salmonella typh coliforms) ENVELOPED VIRUSES (Herpes simplex, varicella-zoster virus, Barr virus, measles virus, mumps virus, virus, respiratory syncytial virus, hepat hantaviruses, and human immunodefici	cytomegalovirus, Epstein- , rubella virus, influenza itis B and C viruses,			Level Disinfection	Low Level Disinfection

# Table 6. Major Classes of Chemical Disinfectants and their Relative Advantages and Disadvantages

Disinfectant	Uses	Advantages	Disadvantages
Alcohols	Intermediate level disinfectant	Fast acting	Volatile
	Disinfect thermometers, external surfaces of some equipment (e.g.,	No residue Non staining	Evaporation may diminish concentration
	stethoscopes). Equipment used for home health care <sup>(59)</sup> Used as a skin antiseptic		Inactivated by organic material May harden rubber or cause deterioration of glues Use in the OR is contraindicated
<b>Chlorines</b> <sup>(131)</sup>	Intermediate level disinfectant	Low cost	Corrosive to metals
Disinfect hydrotherapy tanks, dialysis equipment, cardiopulmonary training manikins, environmental surfaces. Effective disinfectant following blood spills; aqueous solutions (5,000 parts per million) used to decontaminate are after blood has been removed; sodium dichloroisocyanurate powder sprinkle directly on blood spills for decontamination and subsequent cleanup. Equipment used for home health care <sup>(59)</sup> See Table 7 for uses for and dilution of		Fast acting Readily available in non hospital settings	Inactivated by organic material Irritant to skin and mucous membranes Unstable when diluted to usable state (1:9 parts water) Use in well-ventilated areas Shelf life shortens when diluted
Ethylene oxide	chlorines. Used as gas for the sterilization of heat sensitive medical devices	Sterilant for heat or pressure sensitive equipment	Slow acting and requires several hours of aeration to remove residue. One of its carriers (chlorofluorocarbon) is now a restricted chemical.
Formaldehyde	Very limited use as chemisterilant Sometimes used to reprocess hemodialyzers Gaseous form used to decontaminate laboratory safety cabinets	Active in presence of organic materials	Carcinogenic Toxic Strong irritant Pungent odour
Glutaraldehydes	2% formulations — high level disinfection for heat sensitive equipment Most commonly used for endoscopes, respiratory therapy equipment and anesthesia equipment	Noncorrosive to metal Active in presence of organic material Compatible with lensed instruments Sterilization may be accomplished in 6-10 hours	Extremely irritating to skin and mucous membranes Shelf life shortens when diluted (effective for 14-30 days depending on formulation) High cost Monitor concentration in reusable solutions Fixative

#### MANUFACTURERS' RECOMMENDATIONS FOR CONCENTRATION AND EXPOSURE TIME MUST BE FOLLOWED.

Disinfectant	Uses	Advantages	Disadvantages
Hydrogen peroxide	<ul> <li>3% — low level disinfectant</li> <li>Equipment used for home health care<sup>(59)</sup></li> <li>Cleans floors, walls and furnishings</li> <li>6% — high level disinfectant</li> <li>Effective for high level disinfection of flexible endoscopes<sup>(132)</sup></li> <li>Foot care equipment</li> <li>Disinfection of soft contact lenses</li> <li>Higher concentrations used as chemisterilants in specially designed machines for decontamination of heat sensitive medical devices</li> </ul>	Strong oxidant Fast acting Breaks down into water and oxygen	Can be corrosive to aluminum, copper, brass or zinc
Iodophors	Intermediate level disinfectant for some equipment (hydrotherapy tanks, thermometers) Low level disinfectant for hard surfaces and equipment that does not touch mucous membranes (e.g., IV poles, wheelchairs, beds, call bells)	Rapid action Relatively free of toxicity and irritancy	Note: Antiseptic iodophors are NOT suitable for use as hard surface disinfectant Corrosive to metal unless combined with inhibitors Disinfectant may burn tissue Inactivated by organic materials May stain fabrics and synthetic materials
Peracetic acid	High level disinfectant or sterilant for heat sensitive equipment Higher concentrations used as chemisterilants in specially designed machines for decontamination of heat sensitive medical devices	Innocuous decomposition (water, oxygen, acetic acid, hydrogen peroxide) Rapid action at low temperature Active in presence of organic materials	Can be corrosive Unstable when diluted
Phenolics	Low/intermediate level disinfectants Clean floors, walls and furnishings Clean hard surfaces and equipment that does not touch mucous membranes (e.g., IV poles, wheelchairs, beds, call bells)	Leaves residual film on environmental surfaces Commercially available with added detergents to provide one-step cleaning and disinfecting	Do not use in nurseries Not recommended for use on food contact surfaces May be absorbed through skin or by rubber Some synthetic flooring may become sticky with repetitive use
Quaternary ammonium compounds	Low level disinfectant Clean floors, walls and furnishings Clean blood spills <sup>(133)</sup>	Generally non- irritating to hands Usually have detergent properties	DO NOT use to disinfect instruments Non-corrosive Limited use as disinfectant because of narrow microbicidal spectrum

Product	Intended use	<b>Recommended dilution</b>	Level of available chlorine
Household bleach (5% sodium hypochlorite solution with 50,000 ppm <sup>*</sup> available chlorine)	Cleanup of blood spills	Use concentrations ranging from 1 part of bleach to be mixed with 99 parts of tap water (1:100) or one part of bleach to be mixed with 9 parts of tap water (1:10), depending on the amount of organic material (e.g., blood or mucus) present on the surface to be cleaned and disinfected.	0.05% or 500 ppm 0.5% or 5,000 ppm
	To add to laundry water	One part (one 8 ounce cup) of bleach to be mixed with about 500 parts (28 gallons†) of tap water	0.01% or 100 ppm
	Surface cleaning Soaking of glassware or plastic items	One part (one 8 ounce cup) to be mixed with about 50 parts (2.8 gallons) of tap water	0.1% or 1,000 ppm
NaDCC (Sodium dichloro- isocyanurate) powder with 60% available chlorine	Cleanup of blood spills	Dissolve 8.5 g in one litre of tap water	0.85% or 5,000 ppm
Chloramine-T powder with 25% available chlorine	Cleanup of blood spills	Dissolve 20 g in one litre of tap water	2.0% or 5,000 ppm

### Table 7. Directions for Preparing and Using Chlorine-based Disinfectants

<sup>\*</sup> Parts per million

<sup>†</sup> Imperial gallon (4.5 litres)

For further information on uses of bleach in health care refer to article on subject<sup>(131)</sup>.

#### iv) Reuse of chemical disinfectants

Several physical and chemical factors influence disinfectant action, including temperature, pH, relative humidity, and water hardness<sup>(110,128)</sup>. Extremes of acidity or alkalinity can effectively limit growth of microorganisms. Moreover, the activity of antimicrobial agents may be profoundly influenced by relatively small changes in the pH of the medium<sup>(136)</sup>. An increase in pH improves the antimicrobial activity of some disinfectants (e.g., glutaraldehyde, quaternary ammonium compounds) but decreases the antimicrobial activity of others (e.g., phenols, hypochlorites, iodine). The pH influences the antimicrobial activity by altering the disinfectant molecule or the cell surface<sup>(110)</sup>.

Many chemical disinfectants require dilution prior to use. It is mandatory that users follow exactly the manufacturer's directions regarding dilution and mixing. If the concentration of the disinfectant is too low the efficacy will be decreased. If the concentration is too high the risk of the chemical damaging the instrument or causing toxic effects on the user increases. Once diluted some disinfectants may be used (if handled properly) for a period of days or weeks. Dilutions are inherently unstable once mixed and the manufacturer's directions as to duration of use must be followed.

Glutaraldehydes require special discussion. Glutaraldehydes may be in acidic or alkaline formulations, and are usually purchased in concentrated forms and diluted for use. These dilutions are time limited. During reuse, the concentration of active ingredient(s) in the product may drop as dilution of the product occurs (incomplete drying), and while organic impurities accumulate (incomplete cleaning)<sup>(128)</sup>. Chemical test strips are available for determining whether an effective concentration of active ingredients (e.g., glutaraldehyde) is present despite repeated use and dilution. The frequency of testing should be based on how frequently the solutions are used (e.g., used daily, test daily). The strips should not be considered a way of extending the use of a disinfectant solution beyond the expiration date. The glutaraldehyde solution should be considered unsafe when the concentration of glutaraldehyde falls below the minimum effective concentration (MEC) for the product or the dilution falls below 1% glutaraldehyde<sup>(110)</sup>.

#### v) Disinfectants and safety

Chemical disinfectants are a double-edged sword. Although their use is necessary in many routine health care settings, the ability of these products to kill infectious agents also makes them potentially harmful to humans and the environment. Although manufacturers continue to work to improve their formulations, it is unrealistic to expect that highly effective disinfectants that are also completely safe will be available in the near future.

Products containing glutaraldehyde require special attention. Glutaraldehydes are used extensively in the disinfection of semicritical instruments because they are noncorrosive and relatively fast acting in addition to possessing a broad spectrum of activity. However, the pungent and irritating nature of glutaraldehyde fumes and the toxic effects of this disinfectant on skin make it a workplace hazard. The expanding use of glutaraldehyde in many health care settings has led to legislation or regulations in some provinces (e.g., British Columbia) that limit workers' exposure to glutaraldehyde fumes, for instance through the installation of fume hoods and extraction fans in units using glutaraldehyde.

#### vi) Registration of disinfectants in Canada

In Canada, the main control of antimicrobials rests on two pieces of legislation. Antimicrobial products that are labelled for use in health care facilities or food processing plants or on medical devices and are produced for the purposes of disease prevention and health preservation are regulated as drugs under the *Food and Drugs Act and Regulations*, which are administered by the Therapeutic Products Programme, Bureau of Pharmaceutical Assessment, Health Protection Branch, Health Canada. Products used for disinfection or antimicrobial purposes in domestic or household applications, non-food industrial applications, etc. are regulated under the *Pest Control Products Act and Regulations*, which are administered by the Pest Management Regulatory Agency, Health Canada.

For disinfectant drugs, manufacturers must obtain a drug identification number (DIN) from Health Canada prior to marketing. To obtain this they must submit a DIN application, with labelling and supporting data (if required) to the Therapeutic Products Directorate for evaluation. For a DIN to be issued, it must be established that the product is effective and safe for its intended use<sup>(137)</sup>.

The extent of premarket assessment of disinfectant products is based on the relative risk associated with the use of the product, which varies depending on the established knowledge of the active ingredients and the proposed uses for the product. On the basis of this premise, disinfectants or sterilants for use on medical instruments undergo a more rigorous pre-market assessment than disinfectants containing well-known active ingredients for use on environmental surfaces such as floors and walls.

Specific efficacy test methodologies and data requirements for disinfectants to be marketed in Canada are recommended by the Canadian General Standards Board. These requirements vary according to the proposed use(s) of the product, resulting in specific test methodologies and test organisms to match specific claims of efficacy. The most stringent requirements exist for sterilants, products that are to be used for the sterilization of critical instruments. High level disinfectants carry less stringent requirements and are labelled for use on semicritical instruments. Low level disinfectants are labelled for the disinfection of noncritical items and environmental surfaces, and thus have the least stringent efficacy requirements.

The label on the disinfectant must clearly indicate the following information: the product name, a quantitative statement of active ingredient(s), its intended use, the area and site of use, and specific directions for use, including the specific types of surfaces/instruments to be disinfected, any dilution procedure required, the mode of application, the contact time, any cleaning and rinsing procedures, the temperature for use and the reuse period. The labelling must also include appropriate precautionary symbols and statements as well as first aid instruction.

The proposed label claims are reviewed, and in order to be considered acceptable they must have been substantiated with data demonstrating with a great level of confidence that the product is effective under the proposed conditions of use. The label claims must not be misleading.

Should there be any questions regarding the label claims, conditions of use, etc., of a product, the reviewing bureau within the Health Protection Branch (Bureau of Pharmaceutical Assessment) should be contacted for verification. See Appendix 3 for information.

#### vii) Product labelling

- The product label must have a Drug Identification Number (DIN). The presence of a DIN indicates that, upon review, it has been established that the product is safe and effective for its intended use.
- The product label must be read carefully for instructions on use. Failure to do so often leads to inappropriate use, storage or disposal of the product and may expose the patient as well as the health care worker to an increased risk of infections or toxic chemical effects. Inappropriate storage of chemical disinfectants may reduce their shelf life, and if they become contaminated, may also lead to bacterial growth.
- The product label should include mixing instructions, including concentrations for dilution, and length of disinfection time.
- The product label needs to be read for factors that may influence the activity of the disinfectant, such as temperature, pH, relative humidity and water hardness.

#### viii) Pasteurization

Pasteurization is a process of hot water disinfection, which is accomplished through the use of automated pasteurizers or washer disinfectors. Semicritical items suitable for pasteurization include equipment for respiratory therapy and anesthesia.

Exposing respiratory and anesthesia equipment to water above  $75^{0}$  C for 30 minutes is a recognized alternative to chemical disinfection. Items to be pasteurized must be thoroughly cleaned with detergent and water prior to disinfection<sup>(109)</sup>. The items must be totally immersed in water during the pasteurization cycle.

The advantages of pasteurization include its nontoxicity, rapid disinfection cycle, and moderate cost of machinery and upkeep.

The major disadvantages of pasteurization are that (1) it is not sporicidal, (2) it may cause splash burns, (3) there is a lack of standardization of the equipment and (4) there is difficulty validating the effectiveness of the process. The process may be monitored by temperature gauges and timing mechanisms.

Since pasteurization is not a sterilization process, extreme care must be taken to ensure that the process is appropriately performed so that infectious agents considered to be particularly important are inactivated<sup>(138)</sup>. After pasteurization, special care must be taken to dry (residual water tends to collect) and prevent recontamination of the equipment during storage and transport<sup>(138,139)</sup>.

#### ix) Ultraviolet radiation

Microorganisms are inactivated by ultraviolet (UV) light in wavelengths within a range of 250-280 nm<sup>(140)</sup>. Modern mercury-vapor lamps emit radiation within that level. Ultraviolet radiation has several potential applications, but its germicidal effectiveness and use is influenced by organic matter, wavelength, type of suspension, temperature, type of microorganism, and UV intensity (which is affected by distance and dirty tubes). The application of UV light in the hospital is limited to the destruction of airborne organisms or inactivation of microorganisms located on surfaces. Ultraviolet germicidal irradiation is a method of air cleaning that can be used to supplement other tuberculosis control measures. Installing ultraviolet lamps in ventilation ducts has two advantages: high levels of UV irradiation may be produced and, since the UV light is in the duct, the risk of human exposure is reduced or eliminated<sup>(141)</sup>. The Health Canada Guidelines for Preventing the Transmission of Tuberculosis in Canadian Health Care Facilities and Other Institutional Settings<sup>(140)</sup> concludes its discussion of UV germicidal irradiation by saying that it may be a useful adjunct in ventilation ducts or in highrisk areas, such as bronchoscopy suites, autopsy suites, or other areas where patients with undiagnosed TB may be seen frequently.

No data support the use of UV lamps in isolation rooms<sup>(110)</sup>. Portable ultraviolet light devices should not be used for disinfection purposes in community settings (e.g., of esthetic or body piercing equipment).

UV light may cause skin and eye burns, and may theoretically cause cataracts and skin cancer. Problems have occurred when UV lights have not been installed properly or have not been monitored and maintained correctly<sup>(139,140)</sup>.

#### x) Boiling

Boiling is not an acceptable method of sterilization in health care. In home care, boiling has been used to disinfect some items if they do not deteriorate in the process. Home care guidelines should be followed<sup>(59,142,143)</sup>.

The use of boiling water to clean instruments and utensils cannot be called sterilization. Research has shown that boiling water or moist heat at a temperature of  $100^{0}$  C ( $212^{0}$  F) is inadequate for the destruction of bacterial spores and some viruses<sup>(144)</sup>. Another major disadvantage of using boiling water to clean instruments and utensils is that the items are not packaged so that they can be stored and transported without contamination.

#### xi) Sterilization

All critical items that are in contact with the blood stream, nonintact mucous membranes or normally sterile body sites must be sterile. Sterilization is a process, not just a single event. Appropriate procedures must be followed to achieve and maintain sterility. The sterilization process must be validated and documented.

Table 8 summarizes the advantages and disadvantages of sterilization methods as well as recommended applications and monitoring strategies. Manufacturers of sterilizers should be contacted for specific instructions on installation and use of their equipment. Storage and transportation practices must maintain sterility to the point of use. Manufacturers of sterilizers should be specific as to which devices can be sterilized in their machines, and manufacturers of medical devices and equipment should be specific as to the recommended sterilization methods.

#### xii) New technologies

Because of difficulties in disinfecting and sterilizing equipment, such as heat-labile medical devices and devices with small lumens, new technologies are being developed. New technologies will have limited applications (e.g., may not be appropriate for instruments with lumens or may be incompatible with some materials). No single method will work for all hospitals. Policies and procedures must be established to ensure that the reprocessing of equipment follows the principles of infection prevention.

There is controversy about the monitoring of the efficacy of liquid chemical sterilization cycles. Biologic monitoring of liquid chemical sterilization processes using traditional biologic indicators does not appear feasible at this time<sup>(154)</sup>.

#### xiii) Monitoring of the sterilization cycle

Monitoring of sterilization cycles can be divided into three distinct methods<sup>(139)</sup>:

Mechanical:	time and temperature graphs, charts or printouts
Chemical:	time/temperature and/or humidity sensitive tape, strips or pellets <sup>(155)</sup>
<b>Biologic:</b>	spore-laden strips or vials <sup>(156)</sup>

Mechanical and chemical monitors merely provide a visible indicator that the conditions required to achieve sterilization, such as time, temperature and pressure, have been met. Only biologic indicators monitor the actual effectiveness of the sterilization process, which is intended to kill all microbes, including spores<sup>(157)</sup>. An ideal biologic indicator should have the following characteristics: a well characterized organism, widely available, standardized preparation, more resistant to the sterilization process than human pathogens, rapid readout, easy to use, nonpathogenic, and inexpensive<sup>(158)</sup>.

The spores chosen for biologic monitoring must be appropriate for the method of sterilization being monitored<sup>(154)</sup>. For example *Bacillus stearothermophilus* spores are used for steam sterilization and *Bacillus subtilis* for dry heat and ethylene oxide cycles. The frequency of monitoring is indicated in Table 8.

Traditionally, commercially prepared biologic indicators require an incubation time of 24 to 48 hours prior to reading. The recent development of rapid readout biologic monitors, which use fluorometric detection of a spore-bound enzyme at 60 minutes, may offer an alternative to observation of spore growth. Use of rapid readout biologic indicators may enable release of sterilized implants for use or rapid recall of inadequately sterilized devices<sup>(156,157)</sup>. The manufacturer's instructions should be followed in the use of all commercially prepared biologic monitoring systems.

Although indicators are an important part of quality assurance of sterilization processes, the validation of the process and documentation of the operating parameters of the process are of paramount importance. Testing with spore and chemical indicators is only as good as the placement of the spore suspensions or indicators. All sterilization processes should be thoroughly evaluated before being put into service, and at regular intervals afterwards. Autoclaves should be mapped with thermocouples to determine potential cold spots. Filter systems should be tested for leakage. Gas sterilization units should be appropriately validated for such factors as gas concentration, temperature, and relative humidity.

In order to ensure appropriate sterilization processes, health care facility personnel must comply with the manufacturer's recommendations.

The daily operation of the sterilization must be documented by personnel performing the process. This documentation should be reviewed for each operation, and any malfunction should be noted and appropriate action taken to ensure that the product either has been properly treated or is returned for reprocessing<sup>(138)</sup>.

The health care facility should have a protocol on the procedure to follow if monitoring shows equipment failure<sup>(139)</sup>.

## Table 8. Advantages and Disadvantages of Currently Available Sterilization Methods

Sterilization method	Parameters	Monitoring/frequency	Use/advantages	Disadvantages
<ul> <li>Steam</li> <li>a) Small table top sterilizers</li> <li>b) Gravity displacement sterilizers including flash sterilizers</li> <li>c) High-speed vacuum sterilizers</li> </ul>	Raised pressure (preset by manufacturer) to increase temperature to 121° C (133° C for flash sterilizers) Time varies with temperature, type of material and whether the instrument is wrapped or not. Steam must be saturated (narrow lumen items may require prehumidification).	Air detection for vacuum sterilizers - daily before first cycle of day Mechanical - each cycle <sup>(103)</sup> Chemical - each cycle <sup>(103)</sup> Biologic - at least weekly, but preferably daily, and with each load of implantable items ( <i>Bacillus stearothermophilus</i> spores). Loads containing implantable devices shall be monitored and, whenever possible, the implantable devices quarantined until the results of the biologic indicator testing are available <sup>(103)</sup> .	Heat tolerant instruments and accessories Linen Inexpensive Rapid Efficient Non toxic Can be used to sterilize liquids	Unsuitable for anhydrous oils, powders, lensed instruments, heat and moisture sensitive materials. Some table top sterilizers lack a drying cycle.
Flash sterilization	Flash sterilization should be used only in an emergency. Flash sterilization should never be used for implantable devices.	Mechanical - each cycle Chemical - each cycle Biologic - at least once a week but preferably daily <sup>(145)</sup>	Not recommended	If the devices are used before the results of biologic indicators are known, personnel must record which devices were used for specific patients, so that they can be followed if the load was not processed properly <sup>(113,145-148)</sup> . Difficult to monitor The efficacy of flash sterilization will be impaired if all the necessary parameters are not met properly (e.g., time, temper- ature), the device is contaminated with organic matter, air is trapped in or around the device, or the sterilizer or flash pack is not working properly. Sterility cannot be maintained if the device is not wrapped.

#### MANUFACTURERS' RECOMMENDATIONS FOR CONCENTRATION AND EXPOSURE TIME MUST BE FOLLOWED.

Sterilization method	Parameters	Monitoring/frequency	Use/advantages	Disadvantages
Sterilization method Ethylene oxide gas (EtO)	Parameters         EtO concentration based on manufacturer's recommendation         Temperature - variable         Humidity 50%         Time - extended processing time (several hours)	Monitoring/frequency Mechanical - each cycle <sup>(105)</sup> Chemical - each cycle <sup>(105)</sup> Biologic - each cycle <sup>(105)</sup> ( <i>Bacillus subtilis</i> spores)	Use/advantages         Heat sensitive items         Not harmful to heat sensitive and lensed instruments	Expensive EtO systems have been changed because of the elimination of CFCs <sup>(149)</sup> . Toxic to humans Environmental hazard when combined with chlorinated fluorocarbons Requires monitoring of residual gas levels in environment Requires aeration of sterilized products prior to use Lengthy cycle required to achieve sterilization and aeration Highly flammable and explosive, and highly reactive with other chemicals Causes structural damage to
<b>Dry heat</b> a) Gravity convection b) Mechanical convection	Temperatures - time $171^{0}$ C - 60 min $160^{0}$ C - 120 min $149^{0}$ C - 150 min $141^{0}$ C - 180 min $121^{0}$ C - 12 hours	Mechanical - each cycle Chemical - each cycle Biologic - weekly <sup>(139)</sup> ( <i>Bacillus subtilis</i> spores)	Anhydrous oil         Powders         Glass         No corrosive or rusting effect on instruments         Reaches surfaces of instruments that cannot be disassembled         Inexpensive	some devices Lengthy cycle due to slowness of heating and penetration High temperatures may be deleterious to material. Limited packing materials Temperature and exposure times vary, depending on article being sterilized <sup>(139)</sup> .
Glutaraldehyde	Time and temperature must be maintained. Sterilized items must be rinsed with sterile water <sup>(116,119)</sup> . Sterilized items must be handled in a manner that prevents contamination from process through storage to use.	None for sterility Monitors available for pH and dilution concentration	Heat sensitive items	Unable to monitor sterilization Handling provides opportunities for contamination. Copious rinsing with sterile water required to remove all residual disinfectant at termination of cycle. Toxicity of chemicals to health care workers and environment Lengthy process (6-12 hours).

Sterilization method	Parameters	Monitoring/frequency	Use/advantages	Disadvantages
Boiling	Not recommended	None	Not recommended	May be used for dedicated equipment for clients receiving home care (e.g., catheters used by one person) <sup><math>(59,142,143)</math></sup>
Microwave ovens	Not recommended	None	Not recommended	Unable to monitor Unreliable method <sup>(150)</sup> Home use microwaves unable to achieve sterilization <sup>(150)</sup>
Glass bead sterilizers	Not recommended	None	Not recommended	Unable to monitor Cold spots Inconsistent heating Trapped air <sup>(151)</sup>
Hydrogen peroxide vapour	Time and temperature controlled by cycle	Follow manufacturer's instruc- tions Spores of <i>Bacillus</i> <i>stearothermophilus</i> are used as biologic indicators.	Heat sensitive items, e.g., endoscopes Noncorrosive due to short contact times required Environmentally friendly byproducts Low toxicity if devices are aerated <sup>(152)</sup>	Limited field trials on efficacy of sterilization Inactivation by highly absorptive materials such as cellulose paper and linen, thus limiting packaging material Inability to enter deeply into small lumens <sup>(153)</sup> Further evaluation of toxicity is required <sup>(152)</sup> .
Hydrogen peroxide a) liquid (6-25%) b) gas plasma	Time and temperature controlled by cycle	Follow manufacturer's instructions	Heat sensitive items e.g., endoscopes Can be applied to metal and non- metal as well as heat and moisture sensitive instruments Rapid Nontoxic Lack of corrosion to metals and other materials (except nylon)	Limitations on length and lumens of devices that can be effectively sterilized <sup>(112,153)</sup> With gas plasma, inactivation of hydrogen peroxide by highly absorptive materials (linen, cellulose paper) <sup>(153)</sup>

Sterilization method	Parameters	Monitoring/frequency	Use/advantages	Disadvantages
Peracetic acid	Time and temperature controlled by cycle	Follow manufacturer's instructions	Heat sensitive immersible items       e.g., endoscopes, surgical         instruments       Rapid         Automated       Leaves no residue         Effective in presence of organic       matter         Sporicidal at low temperatures	Monitoring of efficacy of sterilization cycle with spore strips is questionable <sup>(154)</sup> Can be used for immersible instruments only Corrosive Material incompatibility with some materials
				Unstable particularly when diluted In vapour form, PAA is volatile, has a pungent odour, is toxic, and is a fire and explosion hazard.
<b>Combination systems</b> of peracetic acid vapour with mixture of hydrogen, oxygen and inert carrier	Time and temperature vary by cycle	Follow manufacturer's instructions	Heat sensitive items Dialysers Rapid Nontoxic Combination system is less corrosive than peracetic acid alone	Limited field trials on efficacy of sterilization Each type of machine needs to be independently verified for effectiveness

#### xiv) Maintenace of sterility

#### a. Packaging

When the process permits, items to be sterilized should be packaged in appropriate wraps before sterilization. One of the main disadvantages of liquid chemical sterilization is that the items are not wrapped before sterilization yet must be stored and transported in a way that minimizes contamination. Ideally, the selected packaging material should possess the following characteristics: it should allow for adequate air removal, sterilant penetration and evacuation; act as a barrier to microorganisms or their vehicles (e.g., dust, vermin) after sterilization is complete; show temperature stability; be strong enough to withstand normal handling; be flexible to permit sealing, wrapping and unwrapping; allow for aseptic removal of sterilized product; produce minimal linting; contain no toxic ingredients or non fast dyes; and maintain seal integrity without resealing upon opening. In the case of rigid containers, gasket integrity must be proven<sup>(103,105,108)</sup>

#### b. Storage

Sterilized items — those sterilized in the health care setting and those purchased as sterile — must be stored in a protected area where products are unlikely to become exposed to moisture, dirt, dust or vermin. Shelf life is event related<sup>(103)</sup>. Event-related shelf life practice recognizes that the product should remain sterile until some event causes the item to become contaminated (e.g., a tear in packaging, packaging becomes wet, or dropped)<sup>(160)</sup>. Event-related factors include frequency and method of handling, and storage area conditions such as appropriate location, space, open/closed shelving, temperature and humidity, and freedom from dust, insects, flooding, and vermin<sup>(138,160)</sup>.

Items purchased as sterile must be used before the expiration date if one is given. Culture should be done only if clinical circumstances suggest infection related to the use of the item. If intrinsic contamination is suspected, notify the Bureau of Radiation and Medical Devices, Health Protection Branch, Health Canada, and local and provincial health departments.

Single-use sterile items that are opened but not used may be able to be re-sterilized. However, it is necessary to ensure that the product can withstand the sterilization method chosen, and that this method will achieve sterilization of the device. The Canadian Healthcare Association has identified principles for the reuse of single-use medical devices and various activities that should be considered in the sterilization procedure<sup>(162)</sup>.

# Recommendations on Cleaning, Disinfection and Sterilization

Each health care setting should have a protocol for reprocessing and maintenance of sterility.

- 1. Items that are received sterile must be maintained sterile until use<sup>(139,163,164)</sup>. **Category A; Grade II**
- Reusable items must be thoroughly cleaned before disinfection or sterilization<sup>(110,120)</sup>. Category A; Grade II
- Reusable items must be adequately rinsed and dried before disinfection or sterilization<sup>(119)</sup> and dried before storage. Category A; Grade II
- 4. Manufacturers' written recommendations for use of chemical disinfectant should be followed.
- 5. Only disinfectants with a DIN should be used (disinfectants approved for use in Canada).
- 6. Respiratory therapy and anesthetic equipment require, at a minimum, high level disinfection<sup>(113,165-167)</sup>.
- Critical items must be sterile<sup>(110)</sup>. Category A; Grade III
- Semicritical items should be disinfected as detailed in Table 5<sup>(116,139)</sup>. Category A; Grade III
- 9. The sterilization process must be monitored by biologic indicator testing:
  - for steam sterilizers: at least weekly, but preferably daily. Loads containing implantable devices shall be monitored and, whenever possible, the implantable devices quarantined until the results of the biologic indicator testing are available<sup>(103)</sup>.
  - for ethylene oxide sterilizers: every load that is to be sterilized<sup>(105)</sup>.
  - for dry heat sterilization: at least weekly<sup>(139)</sup>.
     Category A; Grade III
- The sterilization process must be monitored at each cycle by mechanical and chemical indicators<sup>(139)</sup>.
   Category A; Grade III
- 11. After reprocessing, sterility should be maintained until point of use<sup>(139)</sup>. **Category A; Grade III**

- 12. If a health care facility reuses a single-use medical device, an established protocol must be established and followed to ensure a level of safety, following the framework of the Canadian Healthcare Association<sup>(162)</sup>.
- A procedure for recall of items processed from a load that contained a positive biologic indicator should be established by the institution<sup>(103,105)</sup>. Category A; Grade III
- 14. Flash sterilization is not recommended and should be used only in an emergency, and never for implantable devices. **Category D; Grade III**
- Microwave ovens, glass bead sterilizers and boiling for sterilization should not be used<sup>(144)</sup>. Category D; Grade III
- A specially trained, knowledgable person must be responsible for the disinfection and sterilization process. Category B; Grade III

## **Microbiologic Sampling of Environment**

The results of microbiologic sampling have seldom been useful in directing infection prevention and control programs. Before 1970, routine environmental culturing of inanimate objects was a widely practised infection control surveillance activity in hospitals. However, nosocomial infection rates have seldom been associated with documented colony counts on cultures of air or environmental surfaces where reasonable hygiene exists. Meaningful standards for permissible levels of microbial contamination of the environment do not exist<sup>(168)</sup>. By 1988, LCDC strongly recommended that routine culturing of floors, walls, linen, air and infant formula be discontinued<sup>(71)</sup>.

However, microbiologic sampling may be indicated in selected circumstances, such as an outbreak or other unusual increase in nosocomial infection transmission in which environmental reservoirs are implicated. Such culturing should be based on epidemiologic data and must follow a written plan that specifies the objects to be sampled and the actions to be taken, based on culture results<sup>(169)</sup>.

One major exception to the recommendations to avoid routine spot checking is related to routine sampling of all water and dialysate fluid after dialysis. Gram negative bacteria have the ability to multiply rapidly in water and other fluids associated with the hemodialysis system. These fluids do not need to be sterile, but excessive levels of gram negative bacterial contamination have been associated with numerous pyrogenic and bacteremic reactions<sup>(170)</sup>. A quantitative guideline for interpretation of levels of contamination has been proposed<sup>(115,170-173)</sup>.

The issue of microbiologic sampling of hydrotherapy pools and tanks is controversial. These tanks have been associated with infections. Health care settings that use hydrotherapy pools and tanks may wish to conduct microbiologic sampling as a quality indicator that cleaning and water treatment methods are adequate.

#### **Recommendations for Microbiologic Sampling**

- 1. Routine culturing of air, environmental surfaces or medical devices, either on a scheduled or periodic basis, is not recommended. **Category E; Grade II**
- Routine microbiologic sampling of patient care items purchased as sterile is not recommended. Category D; Grade III
- Routine sampling of the water and dialysate fluid after dialysis is recommended. Category A; Grade II
  - (a) Dialysate water used to prepare dialysate fluid should be checked microbiologically once a month. The level of contamination should not exceed 200 cfu/mL<sup>(174-177)</sup>.
  - (b) Endotoxin contamination in dialysate water used to rinse and reprocess dialysers, and water used to prepare dialyser disinfectant should not exceed 1 ng (5 endotoxin units [EU])/mL<sup>(178,179)</sup>.
  - (c) Dialysate fluid should be sampled once a month at the end of the dialysis treatment. The level of bacterial contamination should not exceed 2,000 cfu/mL. Machine water should be taken from different machines to ensure random sampling<sup>(174-177)</sup>.
- 4. In an outbreak, selective environmental microbiologic sampling may be indicated. Sampling should be obtained from the potential environmental sites implicated in the epidemiologic investigation, as suggested by the outbreak organism(s) or patient

characteristics, (e.g., when clusters of infections occur in patients following endoscopy procedures with possible implication of the equipment, then endoscopes should be sampled)<sup>(119)</sup>. **Category A; Grade II** 

5. If contamination of a commercial product sold as sterile is suspected, infection control personnel should be notified, suspect lot numbers should be recorded, and items from suspected lots should be segregated and quarantined. Appropriate microbiologic assays may be considered. The Medical Devices Bureau, Environmental Health Directorate, Health Protection Branch, Health Canada, provincial health authorities, and manufacturers should be notified promptly. **Category A; Grade III** 

# Housekeeping\*

Although microorganisms are ubiquitous in health care settings, inanimate materials are seldom responsible for the direct spread of infections. Cleaning and maintenance prevent the build-up of soil, dust or other foreign material that can harbour pathogens and support their growth<sup>(180)</sup>. Although there is virtually no risk of transmitting infectious agents to patients by way of the inanimate environment, soiled items could contribute to secondary transmission by contaminating hands of health care workers or by contact with medical equipment that will subsequently come in contact with patients.

Skin antiseptics, except alcohol, should not be used for cleaning inanimate objects.

Cleaning is accomplished with water, detergents and mechanical action. Cleaning reduces or eliminates the reservoirs of potential pathogenic organisms.

Detergents are adequate for most housekeeping<sup>(59)</sup>. Disinfectants are not usually needed in housekeeping activities in health care settings, but are necessary in specified areas (e.g., surgical suites, ICUs, transplant units, surfaces of dialysis machines). Refer to Table 9 for indications on the use of a disinfectant. Disinfection is accomplished by liquid or powdered chemicals. Levels of chemical disinfection vary with the type of product used<sup>(128)</sup>.

## **A. Routine Cleaning**

The aim of cleaning is to achieve a clean environment with regular and conscientious general housekeeping. Extraordinary measures do not need to be taken to disinfect the health care environment<sup>(115)</sup>; high level disinfection and sterilization are not used in house-keeping activities. Visible dust and dirt should be removed routinely with water and detergent and/or vacuuming<sup>(181)</sup>. Duct, fan and air conditioning systems should be cleaned and maintained according to a schedule.

The environment should be kept free of clutter to facilitate housekeeping.

The most frequent source of infection from the inanimate environment is contaminated equipment. Decontamination of patient care equipment is discussed on pages 10-26.

However, environmental water reservoirs have been associated with numerous infections and outbreaks. Examples include faucet aerators, shower heads, sinks, drains, flower vase water, ice machines, water carafes and hydrotherapy baths<sup>(115,173)</sup>. Housekeeping protocols should include careful cleaning of wet surfaces and equipment to prevent the build-up of biofilms.

Hands play a major role in the transmission of human pathogenic microorganisms to susceptible hosts. Hands can acquire known or potential pathogens by contact with objects and animate and inanimate surfaces. Strict adherence to hand washing recommendations (see pages 6-7) is more likely to prevent infections than procedures exceeding routine cleaning of the environment.

#### Housekeeping issues concerning the inanimate environment and the transmission of disease may be summarized as follows:

Prevent objects heavily contaminated with organic material from coming into close contact with portals of entry into the body. For example, patients with nonintact skin, such as those with burns or surgical incisions,

<sup>\*</sup>See Appendix 1 for definitions of the following terms: antiseptics, cleaning, disinfection, fomites, sanitation.

## **Table 9. Cleaning Procedures for Common Items**

Frequency of cleaning will depend on care setting. In acute care settings equipment should be cleaned between patients. In community settings the frequency of cleaning has not been determined.

Surface/object	Procedure	Special considerations	
Horizontal surfaces such as over bed tables, work counters, baby weigh scales,	<ol> <li>Thorough regular cleaning</li> <li>Cleaning when soiled</li> </ol>	Special procedures sometimes called carbolizing are not necessary.	
beds, cribs, mattresses, bedrails, call bells	<ol> <li>Cleaning between patients/clients and after discharge</li> </ol>	Some environmental surfaces may require low level disinfection (e.g., in nurseries, pediatric settings, critical care, burn units, emergency rooms, operating rooms and bone marrow transplantation facilities).	
Walls, blinds, curtains	Should be cleaned regularly with a detergent and as splashes/visible soil occur.		
Floors	1. Thorough regular cleaning	Detergent is adequate in most areas.	
	2. Cleaning when soiled	Blood/body fluid spills should be cleaned up with disposable cloths followed by disinfection with a low level disinfectant.	
	3. Cleaning between patients/clients and after discharge.		
	Damp mopping preferred		
Carpets/upholstery	Should be vacuumed regularly and shampooed as necessary.		
Toys	Should be regularly cleaned, disinfected with a low level disinfectant, thoroughly rinsed, and dried (between patients in acute care setting).	For pediatric settings, toys should be constructed of smooth, nonporous (i.e., not plush) materials to facilitate cleaning and decontamination. Do not use phenolics.	
Toilets and commodes	1. Thorough regular cleaning	These may be the source of enteric pathogens such as <i>C. difficile</i> and <i>Shigella</i> <sup><math>(173)</math>.</sup>	
	2. Cleaning when soiled		
	3. Clean between patients/clients and after discharge.		
	Use a low level disinfectant.		

would be susceptible to infection if exposed to patient care equipment contaminated with feces. Ensure contaminated environmental surfaces are clean to prevent the hands of health care workers or patients/residents/ clients from becoming contaminated<sup>(25)</sup>.

Ensure that contaminated inanimate environments do not contaminate patients/clients/residents through contact with mucous membranes. The transmission of viral and other infections can be reduced by effective cleaning of environmental surfaces<sup>(101)</sup>. During casual contact, transfer of infectious agents from contaminated surfaces to clean surfaces can readily occur<sup>(101)</sup>, and upon inoculation (contaminated hands touching eyes, mouth, other mucous membranes, etc.) could lead to transmission<sup>(182)</sup>. For example, volunteers in a study infected themselves with respiratory syncytial virus (RSV) after handling objects from the room of an RSV-infected patient and then touching their noses and mouths<sup>(115)</sup>.

Many human pathogens can remain viable on porous and nonporous inanimate objects from several hours to several days<sup>(25,129)</sup>. Laboratory-based investigations have clearly demonstrated that the spread of many types of infectious agents can be successfully interrupted by their proper cleaning and, when necessary, disinfection<sup>(101)</sup>.

The frequency of cleaning and disinfecting the health care environment may vary according to the type of surface to be cleaned, the number of people and amount of activity in the area, the risk to patients and the amount of soiling. Horizontal surfaces have a higher number of organisms than vertical surfaces, ceilings and smooth intact walls. For noncritical devices that have contact only with intact skin (e.g., beds, handrails, IV poles, wheelchairs) and for most large environmental surfaces with which humans have little direct contact (e.g., floors, walls, furnishings) routine cleaning is sufficient (Table 9)<sup>(139)</sup>. This can usually be achieved with water and a detergent.

Some environmental surfaces that are frequently touched by health care providers and/or patients, such as call bell lights, surfaces of medical equipment and knobs/handles for adjustment or opening, have greater potential as vehicles for infectious agents. Therefore, careful attention should be paid to the regular cleaning of environmental surfaces that are frequently touched.

For further information on cleaning after the discharge of a patient for whom Contact Precautions have been necessary, refer to Health Canada's *Revision of Isolation and Precaution Techniques*<sup>(98)</sup>.

### **Recommendations for Routine Housekeeping**

- 1. Routine cleaning of environmental surfaces and noncritical patient care items should be performed according to a predetermined schedule and should be sufficient to keep surfaces clean and dust free<sup>(115,180,183)</sup>. Surfaces that are frequently touched by the hands of health care providers and clients, such as call bells, surfaces of medical equipment and knobs for adjustment or opening, require frequent cleaning. **Category B; Grade III**
- 2. Careful mechanical cleaning of environmental surfaces is effective in removing many contaminants from surfaces. **Category A; Grade II**
- Health care facilities should determine a schedule for cleaning and maintaining ducts, fans, and air conditioning systems<sup>(115)</sup>. Category A; Grade II
- An education program for housekeeping staff should help them to understand the effective methods of cleaning and the importance of their work. Category B; Grade III
- 5. Damp rather than dry dusting or sweeping should be performed whenever possible. Any dry cleaning should be done carefully with a chemically treated dry mop or vacuum cleaner (equipped with exhaust filter) rather than a broom. **Category B; Grade III**
- 6. Vacuum cleaners should be used on carpeted areas. Expelled air from vacuum cleaners should be diffused so that it does not aerosolize dust from uncleaned surfaces. **Category B; Grade III**

- 7. During wet cleaning, cleaning solutions and the tools with which they are applied soon become contaminated. Therefore, a routine should be adopted that does not redistribute microorganisms. This may be accomplished by cleaning less heavily contaminated areas first and changing cleaning solutions and cloths/mops frequently. **Category B; Grade III**
- 8. Wet mopping is most commonly done with a doublebucket technique, which extends the life of the solution because fewer changes are required. When a single bucket is used, the solution must be changed more frequently because of increased bioload. **Category B; Grade III**
- Tools used for cleaning and disinfecting must be cleaned and dried between uses. Category B; Grade III
- Mop heads should be laundered daily in areas of great activity and at a set interval for areas of lesser contamination. All washed mop heads must be dried thoroughly before storage<sup>(115)</sup>. Category B; Grade III
- 11. Cleaning agents: a detergent is acceptable for surface cleaning in most areas (Table 9). A low or intermediate grade disinfectant, often called a germicidal detergent<sup>(128)</sup> (see Tables 6 and 7 for examples), may be preferable for cleaning in nurseries, pediatric settings, critical care, burn units, emergency rooms, operating rooms, bone marrow transplantation facilities, and surfaces of dialysis machines. **Category B; Grade III**
- 12. Phenolics should not be used in nurseries (See Tables 6 and 7). Category A; Grade II
- Cleaning and disinfecting agents must be mixed and used according to manufacturers' recommendations. Category A; Grade III
- 14. Protective apparatus: household utility gloves should be worn during cleaning and disinfecting procedures. Manufacturers' directions should be followed for product use to ensure safe handling practices. Category B; Grade III
- Disinfectant fogging should not be done<sup>(184)</sup>.
   Category D; Grade III
- 16. Health care facilities should develop policies for cleaning schedules and methods, which should include the name of the person who is responsible for housekeeping. Category A; Grade III

## **B. Special Cleaning**

## i) Special organisms of epidemiologic significance

Except during outbreaks, no special environmental cleaning techniques are advocated for organisms such as *Clostridium difficile*, methicillin-resistant *Staphylo-coccus aureus* or vancomycin-resistant enterococci<sup>(115,185)</sup>. During an outbreak, thorough environmental cleaning and disinfection with a disinfectant that has demonstrated effectiveness against the specific organism may be required<sup>(186,187)</sup>.

## ii) Blood spills<sup>(84)</sup>

Note: Some recommendations are not graded for strength of evidence because they are from previous *Infection Control Guidelines*, which were not graded.

## **Recommendations for Cleaning Blood Spills**

- Appropriate personal protective equipment should be worn for cleaning up a blood spill. Gloves should be worn during the cleaning and disinfecting procedures. If the possibility of splashing exists, the worker should wear a face shield and gown. For large blood spills, overalls, gowns or aprons as well as boots or protective shoe covers should be worn. Personal protective equipment should be changed if torn or soiled, and always removed before leaving the location of the spill, then hands washed.
- 2. The blood spill area must be cleaned of obvious organic material before applying a disinfectant, as hypochlorites and other disinfectants are substantially inactivated by blood and other materials<sup>(84,109,117)</sup>.
- 3. Excess blood and fluid capable of transmitting infection should be removed with disposable towels. Discard the towels in a plastic-lined waste receptacle.
- 4. After cleaning, the area should be disinfected with a low level chemical disinfectant (e.g., chemical germicides approved for use as "hospital disinfectants", such as quaternary ammonium compounds) or sodium hypochlorite (household bleach). Concentrations ranging from approximately 500 ppm (1:100 dilution of household bleach) sodium hypochlorite to 5000 ppm (1:10 dilution of household bleach) are effective, depending on the amount of organic material (e.g., blood or mucus) present on the surface to be cleaned and disinfected. See Table 7 for directions on the preparation and use of chlorine-based disinfectants. Commercially available chemical disinfectants may be more compatible with certain medical devices that might

be corroded by repeated exposure to sodium hypochlorite, especially the 1:10 dilution<sup>(59,109,133)</sup>. Manufacturers' recommendations for dilutions and temperatures of chemical disinfectants approved for use as hospital disinfectants must be followed.

- 5. For carpet or upholstered surfaces a low level disinfectant may be used. For home health care, a common supermarket disinfectant may be used.
- 6. Previous recommendations have suggested that sodium hypochlorite or chemical germicide should be left on the surface for 10 minutes.
- 7. The treated area should then be wiped with paper towels soaked in tap water. Allow the area to dry.
- 8. The towels should be discarded in a plastic lined waste receptacle.
- 9. Care must be taken to avoid splashing or generating aerosols during the clean up.
- 10. Hands must be thoroughly washed after gloves are removed.
- 11. For blood spills in clinical, public health or research laboratories, refer to recommendations for laboratories<sup>(188,189)</sup>.

**iii)** Surgical settings (modified from Association of Operating Room Nurses<sup>(190-192)</sup>)

## **Recommendations for Cleaning Surgical Settings**

For the purposes of this discussion, surgical settings include the operating room, ambulatory surgical units<sup>(148)</sup>, physicians' offices where invasive procedures are done, intravascular catheterization laboratories, endoscopy rooms and all other areas where invasive procedures may be performed.

- 1. Cleaning procedures should be completed on a scheduled basis, usually daily.
- 2. Areas outside the sterile field contaminated by organic debris should be cleaned as spills or splashes occur.
- 3. Surgical lights and horizontal surfaces, equipment, furniture and patient transport vehicles should be cleaned between patients with a clean cloth and a low level disinfectant.
- 4. Floors should be cleaned with a low level disinfectant/detergent, preferably using a wet vacuum

system between patients<sup>(139)</sup> or, depending on type of procedures carried out, at the end of the day.

- 5. Counter tops and surfaces that have been contaminated with blood or body fluids capable of transmitting infection should be cleaned with disposable towelling, using an appropriate cleaning agent and water as necessary, (e.g., after each procedure, after treatment of each patient/client, at the completion of daily work activities, and after any spill). Surfaces should then be disinfected with a low-level chemical disinfectant or sodium hypochlorite. Loose or cracked work surfaces should be replaced<sup>(84)</sup>.
- 6. All other areas and equipment in the surgical practice setting, (e.g., air conditioning grills and/or filters, cabinets, shelves, walls, ceilings, lounges and locker rooms) should be cleaned according to an established routine.
- 7. Before any piece of portable equipment enters or leaves the operating room, it should be wiped with the approved disinfectant.

## Laundry

The potential for transmission of infection from soiled linen is negligible<sup>(115,172,193-195)</sup>. In fact, there are only a handful of reports suggesting soiled linen as a cause of cross infection. In these studies, there were suspected sources of infection other than the soiled linen<sup>(115,172,193)</sup>. When appropriate precautions are followed by care givers and laundry workers for collecting, transporting, handling, washing, and drying soiled linen, the risk of cross infection can be virtually eliminated<sup>(172,193)</sup>.

All linen that is soiled with blood, body fluids, secretions or excretions or contaminated with lice or scabies should be handled using the same precautions, regardless of source or care setting<sup>(40,115,172,193,196-201)</sup>. If the bag soaks through, an additional outer bag should be used. Recent studies show that the practice of "double bagging" linen from isolation areas or when contamination with certain bacteria or viruses is suspected is not only costly but also unnecessary<sup>(172,193,195,202)</sup>.

Microbial counts on soiled linens are significantly reduced during the mechanical action and dilution of washing and rinsing. With the high cost of energy and use of cold water detergents (which do not require heat to catalyze their actions) hot water washes (>71.1° C for 25 minutes) may not be necessary. Several studies show that low temperature laundering will effectively eliminate residual bacteria to a level comparable with high temperature laundering<sup>(172,193,195)</sup>. When low temperature washes are combined with the addition of bleach (with a total available residual chlorine of 50-150 ppm), residual bacteria on laundry are reduced to below levels found on laundry washed at high temperatures<sup>(172,193)</sup>. See Table 7 for directions on preparing and using chlorine-based disinfectants. Machine drying of linen contributes to a further reduction of residual bacteria(172,193).

Easily laundered clothing should be provided for residents in group facilities or long-term care facilities to avoid the use of garments (e.g., of silk or wool) requiring dry cleaning or other special handling.

The presence of sharps in soiled linens has caused sharps injuries in laundry workers. A needle tracking system may be effective in reducing the number of sharps found in soiled laundry. This approach establishes a system of feedback to personnel deemed responsible for the sharps debris.

#### **Recommendations for Laundry**

#### 1. Collection and handling

- All soiled linen from health care facilities should be handled in the same way for all patients. Category A; Grade II
- b. Linen from persons with a diagnosis of rare viral, hemorrhagic fevers (e.g., Lassa, Ebola, Marburg) requires special handling. For detailed handling instructions refer to Health Canada's *Canadian Contingency Plan for Viral Haemorrhagic Fevers and Other Related Diseases* and, from the Centers for Disease Control and Prevention, *Management of Patients with Suspected Viral Hemorrhagic Fevers*<sup>(203,204)</sup>. Category B; Grade III
- c. Linen should be handled with a minimum of agitation and shaking<sup>(172,193,205)</sup>. Category B;
   Grade III
- d. Sorting and rinsing of linen should not occur in patient care areas, except in facilities that use colourcoded, compartmented soiled linen bag carts into which different types of linen are sorted, e.g.,

personal clothing, towels, reusable incontinence products, bedding. **Category B; Grade III** 

- e. In community or home settings where clothes and linens are not often soiled with blood or body fluids, sorting of linen may take place in care areas<sup>(193)</sup>.
   Category B; Grade III
- f. Heavily soiled linen should be rolled or folded to contain the heaviest soil in the center of the bundle<sup>(172,193)</sup>. Large amounts of solid soil, feces or blood clots should be removed from linen with a gloved hand and toilet tissue and placed into a bed pan or toilet for flushing. Excrement should not be removed by spraying with water (e.g., from clothing, reusable incontinence pads). Category B; Grade III

### 2. Bagging and containment

- a. Soiled linen should be bagged at the site of collection<sup>(172,193,206)</sup>. **Category C; Grade III**
- b. To prevent contamination or soaking through, a single, leakproof bag<sup>(172,195,206)</sup> or a single cloth bag can be used<sup>(205)</sup>. The only indication for a second outer bag is to contain a leaking inner bag<sup>(172,193,195,202)</sup>. Category B; Grade II
- c. Use of water soluble bags is not recommended as these require hot water washes that may cause stains to set. Water soluble bags offer no benefit from an infection control perspective and needlessly add to costs<sup>(172,193)</sup>. **Category B; Grade III**
- d. Laundry carts or hampers used to collect or transport soiled linen need not be covered<sup>(193)</sup>. The practice of placing lids on soiled linen carts is not necessary from an infection control perspective<sup>(193)</sup>. Category B; Grade III
- Bags should be tied securely and not over-filled when transported either by chute or cart<sup>(172)</sup>.
   Category B; Grade III
- f. Linen bags should be washed after each use and can be washed in the same cycle as the linen contained in them<sup>(193)</sup>. Category B; Grade III

## 3. Transport

a. When a laundry chute is used, all soiled linen must be securely bagged and tightly closed. There have been reports of bacteria-laden air being exhausted upwards through these chutes; however, infections have not been associated with chutes<sup>(172,193)</sup>. The chute should discharge into the soiled linen collection area. Laundry chutes should be cleaned on a regular basis with a diluted germicide compatible with the washing process<sup>(206)</sup>. **Category B; Grade III** 

- b. When linens are commercially laundered, adequate separation of clean and dirty laundry in the truck is essential to ensure that there is no opportunity for mixing clean and dirty linens. **Category B; Grade III**
- c. Linen transported by cart should be moved in such a way that the risk of cross contamination is minimized. There is no need to cover carts, although odour control may be a factor<sup>(115,193)</sup>. **Category B;** Grade III
- d. Separate carts should be used for dirty and clean linens. Carts used to transport soiled linens should be cleaned with the cleaning product used in the health care setting after each use. **Category B; Grade III**
- e. Clean linen should be transported and stored in a manner that prevents its contamination and ensures its cleanliness<sup>(115,193,207)</sup>. **Category B; Grade III**

## 4. Washing and drying

- a. If low temperature water is used for laundry cycles, chemicals suitable for low temperature washing at the appropriate concentration should be used. **Category B; Grade III**
- b. High temperature washes (> 71.1° C) are necessary if cold water detergents are not used<sup>(193)</sup>. Category B;
   Grade III
- c. To achieve a level of at least 100 ppm of residual chlorine with household bleach, 2 mL of household bleach should be added for every litre of water. See Table 7 for Directions for Preparing and Using Chlorine-based Disinfectants. Category B; Grade III
- d. In institutional laundry areas, addition of a mild acidic "souring" agent neutralizes the alkalinity from the fabric, water and detergent. This shift in pH from approximately 12 to 5 may inactivate any remaining bacteria and reduce the potential for skin irritation<sup>(193)</sup>. **Category B; Grade III**
- e. Use of a commercial laundry detergent with household bleach (according to product instructions and where suitable for fabrics) and a normal machine wash and machine dry are sufficient to clean soiled linen in a community living or home care setting<sup>(40,196-201)</sup>. **Category B; Grade III**

f. Machine drying or hanging clothing and linens on a clothes line at the home care site is a suitable method for drying. **Category B; Grade III** 

## 5. Dry cleaning

Clothing containing blood, body fluids or excrement that is sent to community dry cleaners should be appropriately labelled. Dry cleaning personnel should be knowledgeable of procedures to handle soiled clothing items.

## 6. Sterile linen

Only surgical gowns and linens used in sterile procedures should be sterilized<sup>(193,207)</sup>. Such linens should be steam sterilized following the normal washing and drying cycle to kill any residual spores. Resterilization of previously sterilized linen requires laundering to rehydrate it. Disposable items for use in sterile procedures may be more cost-effective in some situations. The need for sterilizing linens for nurseries and other areas has not been substantiated<sup>(193)</sup>.

## 7. Protection of laundry workers

- a. Workers should protect themselves from potential cross infection from soiled linen by wearing appropriate protective equipment, such as gloves and gowns or aprons, when handling soiled linens<sup>(193,205-207)</sup>. Reusable gloves should be washed after use, allowed to hang dry, and discarded if punctured or torn. **Category B; Grade III**
- b. Hand washing facilities should be readily available. Category B, Grade II
- c. Personnel should wash their hands whenever gloves are changed or removed<sup>(84)</sup>.Category B; Grade II
- d. Staff in care areas need to be aware of sharps when placing soiled linen in bags. Workers are at risk from contaminated sharps, instruments or broken glass that may be contained with linen in the laundry bags<sup>(172,193)</sup>.
- e. All care givers and laundry workers should be trained in procedures for handling of soiled linen<sup>(193)</sup>.
   Category B; Grade III
- f. Laundry workers, as other health care workers, should be offered immunization against hepatitis B.

## Waste Management\*

The management of waste generated in health care settings has been the subject of much debate in recent years because

- there is a public perception of a higher infection risk from medical as compared with household waste, despite evidence to the contrary;
- environmental concerns have limited the use of incinerator or landfill as a final waste disposal site;
- health care fiscal restraint means that waste management procedures must be based on evidence of risk to workers or the public as well as of decreased risk as a result of the procedures.

The waste management guidelines recommended in this document will be based on the principles of disease transmission and esthetic concerns<sup>(114,208-209)</sup>. The management of waste described in this section will reflect the current understanding of disease transmission and risk, and incorporate an adaptation of the biomedical waste guidelines prepared by the Canadian Standards Association<sup>(210-211)</sup>. Because waste disposal now occurs in many diverse health care settings these guidelines will serve as a reference for both institutional and community health care providers.

The categories of human biomedical waste generated in health care are anatomic, microbiologic/laboratory, blood/body fluid, sharps and isolation waste.

Biomedical waste is not necessarily infectious. Waste documented to be associated with risk of disease transmission are sharps contaminated with blood; as well, aerosolization of the tubercle bacillus from medical waste has been reported<sup>(212)</sup>. The ability of other waste to cause disease depends upon the virulence of the microorganism, susceptibility of the host, and a portal of entry. Because there are no objective methods to determine infection risk from waste, it has become commonplace to regulate waste when it is suspected of containing pathogens capable of producing disease. This practice is not supported by evidence of risk from waste or of decreased disease transmission associated with these practices<sup>(114,208,209)</sup>.

### A. Public Health Risk

Waste generated in health care settings is no more hazardous than household waste. Data demonstrate that household waste contains 100 times more pathogenic organisms than medical waste<sup>(213)</sup>.

There is no evidence that any member of the public has acquired disease from infectious waste<sup>(114,208-209, 214)</sup>. All reports (except one<sup>(212)</sup>) of disease transmission from biomedical waste have been a result of occupational exposure to contaminated sharps in the health care setting. Laboratory workers have unique exposure risks and have incurred exposures that have resulted in transmission of bloodborne pathogens<sup>(84)</sup>. As out-ofhospital care increases, so will the number of sharps disposed of by health care workers in the community<sup>(148,215)</sup> (refer to Table 10). At present, needles may be disposed of in the household waste stream by recreational drug users or persons requiring home health care<sup>(59)</sup>. Accidental needlestick injuries have been reported in 10% of waste industry workers over one year because of improper disposal of needles in residential waste<sup>(217)</sup>. In

<sup>\*</sup>See Appendix 1 for definitions of the following terms: biomedical waste, infectious waste.

## Table 10. Recommendations for Management of Untreated Infectious Waste

Waste category*	Examples	Colour coding packaging†	Handling disposal‡	Special considerations
Anatomic waste	Tissues	Sealed impervious	Incineration, crematorium	For religious or ethical reasons
	Organs	containers		anatomic waste may be buried in a cemetery.
	Body parts			
Microbiologic waste	Diagnostic specimens	Incineration Autoclavable bags and plastic	Incineration or decontamination by autoclave for landfill <sup>(211)</sup>	
	Laboratory cultures			
	Vaccines	waste holding bags for general waste		
Blood/body fluid waste	Phlebotomy bottles	Sealed impervious containers	Sanitary sewer if permitted by local regulatory authorities or incineration	
	Drainage collection units			
	Suction containers with blood			
	Placentas from home deliveries			
Other waste	Gloves	Impervious waste holding bags or double bag	Landfill	It is inappropriate to specify a minimum thickness of plastic bag as plastic materials vary extensively in their physical and mechanical properties.
	Sponges			
	Dressings			
	Surgical drapes soiled or soaked			
	with blood or secretions			
Sharps	Needles	Puncture resistant sharps containers	Incineration or landfill disposal (home health care)	For health care provided in the home use a puncture-resistant container. Glass containers should not be used. The lid should be secured before disposal into
	Blood syringes			
	Lancets			
	Clinical glass			
				household waste. The local
				municipality or public health
				department should be contacted before disposal <sup>(59,148,210,215)</sup>
Isolation waste	Lassa fever	Transport Canada approved, sealed, impervious container	Incineration	Contact the local public health authority <sup>(216)</sup> .
	Marburg virus disease			
	Ebola virus disease			

 <sup>\*</sup> As per definitions
 \* Biohazard symbol is required on all packaging for incineration; colour coding varies provincially and regionally.
 \* All transportation of infectious waste must comply with the *Transportation of Dangerous Goods Act*, Transport Canada<sup>(216)</sup>.

Canada, tracking methods for community-acquired needlestick injuries, both in health care workers and non health workers such as waste industry workers, require further development<sup>(218)</sup>.

Esthetics plays a role in the management of biomedical waste. The waste generated during health care delivery is perceived by the public to pose a threat to health. However, the public perception of hazard does not equate with the actual risk of contracting infectious diseases<sup>(213,219,220)</sup>.

Blood-soaked waste has also received much attention. Increased public concern over bloodborne pathogens has resulted in the erroneous extension of bloodborne pathogen precautions to treat **all** blood/body fluid waste as potentially infectious. Items soaked or dripping with blood, contained in an impervious plastic bag before being sent to the landfill, pose no threat to the public health. Special treatment (e.g., incineration) of blood soaked waste is not required, and has enormous cost and environmental implications<sup>(59,211,221,222)</sup>.

Sharps contaminated with body fluid<sup>(84)</sup> and untreated microbiologic waste<sup>(188)</sup> require special handling and treatment. Sharps must be contained in a puncture-proof container. Sharps and microbiologic waste should be incinerated prior to disposal. Local environmental and health regulatory authorities should be consulted when implementing the waste treatment and disposal recommended in this document.

#### **B.** Treatment of Waste

The treatment of infectious waste to render it noninfectious, in some instances, may be stipulated by local regulatory authorities. The principles of appropriate treatment methods follow.

#### i) Chemical decontamination

Chemical decontamination of infectious fluids is generally not indicated except for the cleanup of blood spills<sup>(84)</sup>. Chemical treatment of sharps, such as adding a disinfectant to a sharps container, does not render sharps safe for further handling.

#### ii) Steam sterilization

Steam sterilization is most often used for decontamination of microbiologic waste before final disposal in a landfill<sup>(188)</sup>. Steam autoclaving is an appropriate method of treating microbiology laboratory waste<sup>(189)</sup>, blood and body fluid waste (if applicable), and non-anatomic animal wastes. It must not be used for treating anatomic waste<sup>(210)</sup>. The penetration of steam into the waste is essential for decontamination, and therefore the packaging of waste, and the volume and loading of the autoclave are crucial. Biologic monitoring should be used to confirm that a routine cycle achieves sterilization<sup>(210)</sup>.

#### C. Disposal Methods for Waste

There are three common methods of waste disposal for biologic waste in Canada, which may vary in availability according to location.

#### i) Landfill

It is acceptable to dispose of specific categories of waste in a properly managed landfill provided there are procedures in place to protect workers from contact with the waste. Studies have shown that bacteria and viruses in a landfill are significantly reduced in number by processes such as thermal inactivation and adsorption of organic material in the solid waste. The leachate similarly contains relatively low concentrations of pathogenic organisms and therefore poses minimal risk to the surrounding environment<sup>(214)</sup>. It is, however, an overall environmental goal to reduce waste of all types, including waste for disposal into the landfill. The landfill disposal method is inexpensive when compared with incineration<sup>(220)</sup>. Local regulations must be followed.

#### ii) Sanitary sewer

The sanitary sewer is an acceptable method of disposal of blood, suctioned fluids, excretions and secretions<sup>(210)</sup>. The disposal of such liquids into sanitary sewers must conform to municipal sewerage by-laws and provincial regulations and legislation<sup>(211)</sup>.

#### iii) Incineration

Incineration is the process that converts combustible materials into noncombustible ash, achieving a reduction of 90% by volume or 75% by weight. The product gases are vented into the atmosphere, and the treatment residue may be disposed of in a landfill. Provincial and territorial regulatory authorities issue requirements for many aspects of incinerator operation and emissions<sup>(210)</sup>.

#### **D.** Safety for Waste Handlers

Persons handling infectious waste are at potential risk of exposure to pathogens from sharps or infectious waste leaking from containers.

#### **Recommendations for Waste Management**

- Local environmental and health regulations should be followed when planning and implementing treatment and disposal policies for biologic waste. Category B; Grade III
- Specific categories of biologic waste may be disposed of in a properly managed landfill provided that there are procedures in place to protect workers and the public from contact with the waste. Category B; Grade III
- 3. Medical waste, (e.g., gloves, sponges, dressings, surgical drapes soiled or soaked with blood or secretions) may be contained in impervious waste holding bags or double bags and may be disposed of in a landfill<sup>(114,208,209)</sup>. **Category B; Grade III**
- 4. Blood, suctioned fluids, excretions and secretions may be disposed of in a sanitary sewer if local regulations permit. **Category B; Grade III**
- 5. Anatomic waste, (e.g., tissues, organs, body parts) should be packaged in a sealed, impervious container that is not easily torn or penetrated in transport, and may be disposed of in an incinerator or crematorium (Table 10). **Category B; Grade III**
- Microbiologic waste, (e.g., diagnostic specimens, laboratory cultures, vaccines) should be packaged in incineration or autoclavable bags and treated by incineration or steam sterilization before disposal in a landfill. Adhere to *Laboratory Biosafety Guidelines*<sup>(188,210)</sup>. Category B; Grade III
- Sharps (e.g., needles, syringes, blades, lancets, clinical glass) should be contained in puncture-resistant sharps containers for transport and treated by incineration or landfill (home health care), depending on local regulations (Table 10)<sup>(211,218)</sup>. Category A; Grade II
- 8. Isolation waste (waste containing pathogens categorized as Risk Group 4 agents such as Lassa fever, Marburg and Ebola viruses) must be contained in a Transport Canada approved, sealed, impervious

container for transport and should be treated by incineration. Under the *Transportation of Dangerous Goods Regulations*, Schedule 16, mandated by Transport Canada (TC), any shipment of a Risk Group 4 agent must have a TC approved Emergency Response Assistance Plan in place before shipment<sup>(216)</sup>. The local public health authority must be contacted<sup>(203)</sup>. **Category B; Grade III** 

- A biohazard symbol is required on all waste packaged for incineration. Regulations regarding colour coding may vary provincially. Category B; Grade III
- 10. All transportation of infectious waste must comply with the *Transportation of Dangerous Goods Act and Regulation*, Transport Canada<sup>(216)</sup>.
- Infectious waste must be stored in a designated location with access limited to authorized personnel. Refrigerated space should be provided for lockable, closed storage of laboratory waste that will be disposed of off site<sup>(188)</sup>. Provincial/territorial regulations for specific storage requirements should be followed. **Category B; Grade III**
- Health care facilities should choose waste hauling, treatment, and disposal firms carefully since the waste generator is held directly accountable for ensuring that all stages of transportation and disposal are carried out in a safe and legal manner<sup>(188)</sup>.
   Category B; Grade III
- Written policies and procedures to promote the safety of waste handlers should be established with input from persons handling the waste. Category B; Grade III
- 14. Waste handlers should wear protective apparatus appropriate to the risk, (e.g., protective footwear and heavy work gloves). **Category B; Grade III**
- 15. Waste handlers should be offered hepatitis B immunization.

# References

- 1. Larson E. *A causal link between handwashing and risk of infection? Examination of the evidence.* Infect Control Hosp Epidemiol 1988;9:28-36.
- 2. Mermel LA, McCormick RD, Springman SR et al. The pathogenesis and epidemiology of catheterrelated infection with pulmonary artery swan-ganz catheters: a prospective study utilizing molecular subtyping. Am J Med 1991;91:197-205.
- 3. Doebbeling BN, Stanley GL, Sheetz CT et al. Comparative efficacy of alternative hand-washing agents in reducing nosocomial infections in intensive care units. N Engl J Med 1992;327:88-93.
- 4. Larson E, Mayur K, Laughon BA. *Influence of two* handwashing frequencies on reduction in colonizing flora with three handwashing products used by health care personnel. Am J Infect Control 1989;17:83-88.
- Raad II, Hohn DC, Gilbreath BJ. Prevention of central venous catheter-related infections by using maximal sterile barrier precautions during insertion. Infect Control Hosp Epidemiol 1994;15:231-38.
- 6. Maki DG, Ringer M, Alvardo CJ. Prospective randomised trial of povidone-iodine, alcohol, and chlorhexidine for prevention of infection associated with central venous and arterial catheters. Lancet 1991;338:339-43.
- 7. Nystrom B. *Impact of handwashing on mortality in intensive care: Examination of the evidence*. Infect Control Hosp Epidemiol 1994;15:435-36.

- Gruendemann BJ, Larson EL. Antisepsis in current practice. In: Rutala WA, ed. Disinfection, sterilization and antisepsis in health care. Washington, DC: Association for Professionals in Infection Control and Epidemiology, Inc and Polyscience Publications, Inc, 1998:183-95.
- 9. Jones RN, Marshall SA, Pfaller MA et al. Nosocomial enterococcal blood stream infections in the SCOPE program: antimicrobial resistance, species occurrence, molecular testing results, and laboratory testing accuracy. Diagn Microbiol Infect Dis 1997;29:95-102.
- 10. Larson EL. *Hand washing and skin preparation for invasive procedures.* In: Olmsted RN, ed. *APIC infection control and applied epidemiology principles and practice.* St. Louis: Mosby, 1996:Chapter 19.
- 11. Garner JS, Favero MS. *Guideline for handwashing and hospital environmental control, 1985.* Atlanta Centers for Disease Control and Prevention, 1985:1-20.
- Albert RK, Condie F. Hand-washing patterns in medical intensive-care units. N Engl J Med 1981;304:1465-66.
- 13. Graham M. Frequency and duration of handwashing in an intensive care unit. Am J Infect Control 1990;18:77-81.
- 14. Zimakoff J, Kjelsberg AB, Larsen AS. A multicentre questionnaire investigation of attitudes towards hand hygiene, assessed by the staff in fifteen hospitals in Denmark and Norway. Am J Infect Control 1992;20:58-64.

- 15. Health and Welfare Canada. *Infection control* guidelines part II. Guidelines for the prevention of surgical wound infections. Ottawa, 1988:13-25.
- 16. Larson E. Handwashing and skin physiologic and bacteriologic aspects. Infect Control 1985;6:14-23.
- 17. McGinley KJ, Larson EL, Leyden JJ. *Composition and density of microflora in the subungual space of the hand*. J Clin Microbiol 1988;26:950-53.
- Pottinger J, Burns S, Manske C. Bacterial carriage by artificial versus natural nails. Am J Infect Control 1989;17:340-44.
- 19. Wynd CA, Samstag DE, Lapp AM. *Bacterial carriage on the fingernails of OR nurses*. AORN 1994;60:796-805.
- 20. Larson EL, APIC Guidelines Committee. *APIC Guideline for hand washing and hand antisepsis in health care settings*. Am J Infect Control 1995;23:251-69.
- 21. Reybrouck G. *Handwashing and hand disinfection*. J Hosp Infect 1986;8:23.
- 22. Bettin K, Clabots C, Mathie P et al. *Effectiveness of liquid soap vs chlorhexidine gluconate for the removal of Clostridium difficile from bare hands and gloved hands*. Infect Control Hosp Epidemiol 1994;15:697-702.
- 23. Gould D, Chamberlain A. *Gram-negative bacteria*. *The challenge of preventing cross-infection in hospital wards: a review of the literature*. J Clin Nurs 1994;3:330-45.
- 24. Gould D. *The significance of hand-drying in the prevention of infection*. Nurs Times 1994;90:33-5.
- 25. Noskin GA, Stosor V, Cooper I et al. *Recovery of vancomycin-resistant Enterococci on fingertips and environmental surfaces*. Infect Control Hosp Epidemiol 1995;16:577-81.
- 26. Ansari SA, Springthorpe VS, Sattar SA et al. Comparison of cloth, paper, and warm air drying in eliminating viruses and bacteria from washed hands. Am J Infect Control 1991;19:243-49.
- 27. Matthews JA, Newsom SWB. *Hot air electric hand driers compared with paper towels for potential spread of airborne bacteria*. J Hosp Infect 1987;9:85-8.

- 28. Meers PD, Leong KY. *Hot-air hand driers*. J Hosp Infect 1989;14:169-81.
- 29. Hanna PJ, Richardson BJ, Marshall M. *A* comparison of the cleaning efficiency of three common hand drying methods. Appl Occup Environ Hygiene 1996;11:37-43.
- 30. Ngeow YF, Ong HW, Tan P. *Dispersal of bacteria by an electric air hand dryer*. Malays J Pathol 1989;11:53-6.
- 31. Blackmore MA. *A comparison of hand drying methods*. Cater Health 1989;1:189-98.
- 32. Minakuchi K, Yamamoto Y, Matsunaga K et al. *The antiseptic effect of a quick drying rubbing type povidone-iodine alcoholic disinfectant solution.* Postgrad Med J 1993;69:S23-26.
- 33. Webster J, Faogali JL, Cartwright D. *Elimination* of methicillin-resistant staphylococcus aureus from a neonatal intensive care unit after hand washing with triclosan. J Paediatr Child Health 1994;30:59-64.
- Maki DG. Infections caused by intravascular devices used for infusion therapy: pathogenesis, prevention, and management. In: Bisno AL, Waldvogel FA, eds. Infections associated with indwelling medical devices. 2nd ed. Washington, DC: American Society for Microbiology Press, 1994:155-212.
- 35. Wade JJ, Casewell MW. *The evaluation of residual antimicrobial activity on hands and its clinical relevance*. J Hosp Infect 1991;18:23-28.
- Wade JJ, Desai N, Casewell MW. Hygienic hand disinfection for the removal of epidemic vancomycin-resistant Enterococcus faecium and gentamicin-resistant Enterobacter cloacae. J Hosp Infect 1991;18:211-18.
- 37. Ehrenkranz NJ, Alfonso BC. Failure of bland soap handwash to prevent hand transfer of patient bacteria to urethral catheters. Infect Control Hosp Epidemiol 1991;12:654-52.
- 38. Larson E. *Handwashing: It's essential even when you use gloves.* Am J Nurs 1989;89:934-39.

- 39. Namura S, Nishijima S, Asada Y. *An evaluation* of the residual activity of antiseptic handrub lotions: an 'in use' setting study. J of Dermatol 1994;21:481-85.
- 40. Smith PW, Rusnak PG. *Infection prevention and control in the long-term-care facility*. Am J Infect Control 1997;25:488-512.
- 41. Kabara JJ, Brady MB. Contamination of bar soaps under "in-use" conditions. J Environ Pathol Toxicol Oncol 1984;5:1-14.
- 42. Butz AM, Laughon BE, Gullette DL et al. *Alcohol-impregnated wipes as an alternative in hand hygiene*. Am J Infect Control 1990;18:70-76.
- 43. France DR. *Survival of Candida albicans in hand creams*. N Zealand Med J 1968;67:552-54.
- 44. Morse LJ, Williams HL, Grann FP et al. *Septicemia due to Klebsiella pneumoniae originating from a hand cream dispenser*. N Engl J Med 1967;277:472-73.
- 45. Morse LJ, Schonbeck LE. *Hand lotions a potential nosocomial hazard*. N Engl J Med 1968;278:376-78.
- O'Connor DO, Rubino JR. *Phenolic compounds*. In: Block SS, ed. *Disinfection, sterilization, and preservation*. 4th ed. Philadelphia: Lea & Febiger, 1991:204-24.
- 47. Casewell MW, Law MM, Desai N. A laboratory model for testing agents for hygienic hand disinfection: handwashing and chlorhexidine for the removal of Klebsiella. J Hosp Infect 1988;12:163-75.
- 48. Bellamy K, Alcock R, Babb JR et al. *A test for the assessment of 'hygienic' hand disinfection using rotavirus*. J Hosp Infect 1993;24:201-10.
- 49. Kjølen H, Andersen BM. Handwashing and disinfection of heavily contaminated hands – effective or ineffective? J Hosp Infect 1992;21:61-71.
- 50. Ansari SA, Sattar SA, Springthorpe VS et al. In vivo protocol for testing efficacy of handwashing agents against viruses and bacteria: experiments with rotavirus and Escherichia coli. Appl Environ Microbiol 1989;55:3113-18.

- Rotter ML, Koller W. Test models for hygienic handrub and hygienic handwash: the effects of two different contamination and sampling techniques. J Hosp Infect 1992;20:163-71.
- 52. Rotter ML, Koller W. A laboratory model for testing agents for hygienic hand disinfection: handwashing and chlorhexidine for the removal of Klebsiella. J Hosp Infect 1990;15:189-99.
- 53. Steinmann J, Nehrkorn R, Meyer A et al. *Two in-vivo* protocols for testing virucidal efficacy of handwashing and hand disinfection. Zbl Hyg 1995;196:425-36.
- Gröschel DHM, Pruett TL. Surgical antisepsis. In: Block SS, ed. Disinfection, sterilization, and preservation. 4th ed. Philadelphia and London: Lea & Febiger, 1991:642-52.
- Rotter ML, Koller W, Neumann R. The influence of cosmetic additives on the acceptability of alcoholbased hand disinfectants. J Hosp Infect 1991;18 (Supp. B):57-63.
- 56. Rotter ML, Koller W. Surgical hand disinfection: effect of sequential use of two chlorhexidine preparations. J Hosp Infect 1990;16:161-66.
- 57. Namura S, Nishjima S, Mitsuya K et al. *Study of the efficacy of antiseptic handrub lotions with hand washing machines.* Journal of Dermatology 1994;21:405-10.
- Rotter ML. Hand washing and hand disinfection. In: Mayhall CG, ed. Hospital epidemiology and infection control. Baltimore: Williams & Wilkins, 1996:1052-68.
- 59. Simmons B, Trusler M, Roccaforte J et al. *Infection control for home health*. Infect Control Hosp Epidemiol 1990;11:362-70.
- 60. Larson E, Bobo L. *Effective hand degerming in the presence of blood*. J Emerg Med 1992;10:7-11.
- 61. Salisbury DM, Hutfilz P, Treen LM et al. *The effect* of rings on microbial load of health care workers' hands. Am J Infect Control 1997;25:24-27.
- 62. Baumgardner CA, Maragos CS, Walz J et al. Effects of nail polish on microbial growth of fingernails: dispelling sacred cows. AORN 1993;58:84-88.

- 63. Conly JM, Hill S, Ross J et al. *Handwashing* practices in an intensive care unit: the effects of an educational program and its relationship to infection rates. Am J Infect Control 1989;17:330-39.
- 64. Jarvis WR. Handwashing the Semmelweis lesson forgotten? Lancet 1994;344:1311-2.
- 65. Dubbert P, Dolce J, Richter W et al. *Increasing ICU staff handwashing: effects of education and group effect.* Infect Control Hosp Epidemiol 1990;11:191-94.
- 66. Wurtz R, Moye G, Jovanovic B. *Handwashing* machines, handwashing compliance, and potential for cross-contamination. Am J Infect Control 1994;22:228-30.
- 67. Larson E, McGeer A, Quaraishi A et al. *Effect of an automated sink on handwashing practices and attitudes in high-risk units*. Infect Control Hosp Epidemiol 1991;12:422-28.
- 68. Larson E, Kretzer E. *Compliance with handwashing and barrier precautions*. J Hosp Infect 1995;30:88-106.
- 69. Larson E, Bryan J, Adler L et al. *A multifaceted approach to changing handwashing behavior*. Am J Infect Control 1997;25:3-10.
- Hughes WT, Williams B, Williams B et al. *The* nosocomial colonization of *T. Bear*. Infect Control 1986;7:495-500.
- Health and Welfare Canada. *Infection control guidelines part V: hospital environmental control.* Ottawa: Health and Welfare Canada, 1988.
- 72. Orth B, Frei R, Itin P et al. *Outbreak of invasive* mycoses caused by **Paecilomyces lilacinus** from a contaminated skin lotion. Ann Intern Med 1996;125:799-806.
- 73. Becks VE, Lorenzoni NM. *Pseudomonas Aeruginosa* outbreak in a neonatal intensive care unit: a possible link to contaminated hand lotion. Am J Infect Control 1995;23:396-98.
- 74. Olsen RJ, Lynch P, Coyle MB et al. *Examination* gloves as barriers to hand contamination in clinical practice. JAMA 1993;270:350-53.
- 75. Ojajärvi J. *Handwashing in Finland*. J Hosp Infect 1991;18:35-40.

- 76. Gould D. *Infection control: making sense of hand hygiene*. Nurs Times 1994;90:63-4.
- 77. Steere AC, Mallison GF. *Handwashing practices* for the prevention of nosocomial infections. Ann Intern Med 1975;83:683-90.
- Larson EL, Eke PI, Laughon BE. *Efficacy of* alcohol-based hand rinses under frequent-use conditions. Antimicrob Agents Chemother 1986;30:542-44.
- 79. Hamann CP, Nelson JR. *Permeability of latex and thermoplastic elastomer gloves to the bacteriophage øX174*. Am J Infect Control 1993;21:289-96.
- 80. Anon. Vancomycin-resistant enterococci in hospitals in the United Kingdom. CDR Weekly 1995;5:281,284.
- 81. Kjolen H, Andersen BM. *Handwashing and disinfection of heavily contaminated hands – effective or ineffective*? J Hosp Infect 1992;21:61-71.
- Health and Welfare Canada. *Infection control guidelines: isolation and precaution techniques.* revised. Ottawa: Canada Communications Group, 1990.
- 83. Federal Centre for AIDS. *Recommendations for prevention of HIV transmission in health-care settings*. CDWR 1987;13S3:1-10.
- 84. Health Canada. *Infection control guidelines* preventing the transmission of bloodborne pathogens in health care and public services settings. CCDR 1997;23S3:1-42.
- 85. Lynch P, Cummings JM, Roberts PL et al. Implementing and evaluating a system of generic infection precautions: body substance isolation. Am J Infect Control 1990;18:1-12.
- 86. Korniewicz DM, Kirwin M, Larson E. *Do your* gloves fit the task? Am J Nursing 1991:38-40.
- 87. Health Canada. *Labelling of medical gloves to show primary materials of composition*. 1995; Information Letter No. 814.
- 88. Korniewicz DM. *Barrier protection of latex*. Immunol Allergy Clinics N Am 1995;15:123-37.

- Korniewicz DM, Kirwin M, Cresci K et al. Leakage of latex and vinyl exam gloves in high and low risk clinical settings. Am Ind Hyg Assoc J 1993;54:22-6.
- 90. Korniewicz DM, Kelly KJ. Barrier protection and latex allergy associated with surgical gloves. AORN 1995;61:1037-44.
- 91. Korniewicz DM, Laughon BE, Cyr WH et al. Leakage of virus through used vinyl and latex examination gloves. J Clin Microbiol 1990;28:787-88.
- 92. DeGroot-Kosolcharoen J, Jones JM. *Permeability* of latex and vinyl gloves to water and blood. Am J Infect Control 1989;17:196-201.
- 93. Connor TH. Permeability testing of glove materials for use with cancer chemotherapy drugs. Oncology 1995;52:256-59.
- 94. Fricker C, Hardy JK. *The effect of an alternate* environment as a collection medium on the permeation characteristics of solid organics through protective glove materials. Am Ind Hyg Assoc J 1994;55:738-42.
- 95. Johnson S, Gerding DN, Olson MM et al. *Prospective, controlled study of vinyl glove use to interrupt* Clostridium difficile nosocomial transmission. Am J Med 1990;88:137-40.
- 96. Kotilainen H, Brinker J, Avato J et al. *Latex and* vinyl examination gloves: quality control procedures and implications for the health care workers. Arch Intern Med 1989;149:2749-53.
- 97. Sussman G, Gold M. *Guidelines for the* management of latex allergy and safe latex use in health care facilities. Canadian Healthcare Association. Ottawa, 1996.
- 98. Health Canada. *Routine practices and additional precautions for preventing transmission of infection in health care Revision of isolation and precaution techniques.* (1999, In press).
- 99. Doebbeling BN, Pfaller MA, Houston AK et al. Removal of nosocomial pathogens from the contaminated glove: implications for glove reuse and handwashing. Ann Intern Med 1988;109:394-98.

- 100. Richet H, Hubert B, Nitemberg G et al. Prospective multicenter study of vascular-catheter-related complications and risk factors for positive centralcatheter cultures in intensive care unit patients. J Clin Microbiol 1990;28:2520-25.
- 101. Sattar SA, Jacobsen H, Rahman H, et al. Interruption of rotavirus spread through chemical disinfection. Infect Control Hosp Epidemiol 1994;15:751-56.
- Treasury Board. Occupational safety and health. Treasury Board Manual, 5th ed., 1994 (Cat. No. BT45-3/1994-E), Chapters 1-6.
- 103. Canadian Standards Association. *Effective* sterilization in hospitals by the steam process. CAN/CSA-Z314.3-M91. Toronto: Canadian Standards Association, 1991.
- 104. Canadian Standards Association. *Steam sterilizers for hospitals*. CAN/CSA-Z314.7-M91. Toronto: Canadian Standards Association, 1991.
- 105. Canadian Standards Association. *Effective* sterilization in hospitals by the ethylene oxide process. CAN/CSA-Z314.2-M91. Toronto: Canadian Standards Association, 1991.
- 106. Canadian Standards Association. Selection, use, maintenance, and laundry of reusable textile wrappers for sterilization products in health care facilities. CAN/CSA-Z314.10-M90. Toronto: Canadian Standards Association, 1990.
- 107. Canadian Standards Association. Performance requirements of test packs for use in hospitals. CAN/CSA-Z314.12-M91. Toronto: Canadian Standards Association, 1991.
- 108. Canadian Standards Association. Selection and use of rigid sterilization containers. CAN/CSA-Z314.14-93. Toronto: Canadian Standards Association, 1993.
- 109. Rutala WA. APIC guidelines for selection and use of disinfectants. Am J Infect Control 1990;18:99-117.
- 110. Rutala WA. Selection and use of disinfectants in health care. In: Mayhall CG, ed. Hospital epidemiology and infection control. Baltimore: Williams & Wilkins, 1996:913-36.

- 111. Rutala WA. *Disinfection and sterilization of patient-care items*. Infect Control Hosp Epidemiol 1996;17:377-84.
- 112. Alfa MJ. Preliminary report: comparative evaluation of the effectiveness of gas sterilizers. CCDR 1995;21:80-3.
- Reichert M, Young JH. Sterilization technology for the health care facility. 2nd ed. Gaithersburg, Maryland: Aspen Publishers, Inc., 1997.
- 114. Rutala WA. Disinfection, sterilization, and waste disposal. In: Wenzel RP, ed. Prevention and control of nosocomial infections. 3rd ed. Baltimore: Williams & Wilkins, 1997:539-93.
- 115. Rhame FS. *The inanimate environment*. In: Bennett JV, Brachman PS, eds. *Hospital infections*. 4th ed. Philadelphia: Lippincott-Raven, 1998:299-324.
- 116. Rutala WA, APIC Guidelines Committee. *APIC guideline for selection and use of disinfectants*. Am J Infect Control 1996;24:313-42.
- Favero MS, Bond WW. Chemical disinfection of medical and surgical materials. In: In Block S.S., ed. Disinfection, sterilization and preservation. 4th ed. Philadelphia: Lea and Febiger, 1991:617-41.
- 118. Bond WW. Endoscope reprocessing: problems and solutions. In: Rutala WA, ed. Disinfection, sterilization and antisepsis in health care. Washington: Association for Professionals in Infection Control and Epidemiology, Inc. and Polyscience Publications, Inc., 1998:151-63.
- 119. Alfa MJ, Olson N, DeGagne P et al. New low temperature sterilization technologies: microbicidal activity and clinical efficacy. In: Rutala WA, ed. Disinfection, sterilization and antisepsis in health care. Washington, DC: Association for Professionals in Infection Control and Epidemiology, Inc. and Polyscience Publications, Inc., 1998:67-78 & 101-03.
- 120. Jacobs PT, Wang JH, Gorhan RA et al. Cleaning: principles, methods and benefits. In: Rutala WA, ed. Disinfection, sterilization and antisepsis in health care. Washington, D.C.: Association for Professionals in Infection Control and Epidemiology, Inc. and Polyscience Publications, Inc., 1998:165-81.

- 121. DesCoteaux JG, Poulin EC, Julien M et al. Residual organic debris on processed surgical instruments. AORN 1995;62:23-30.
- 122. Rutala WA, Weber DJ. *Low-temperature sterilization technologies: do we need to redefine "sterilization"?* Infect Control Hosp Epidemiol 1996;17:87-91.
- 123. Canadian Standards Association. *Reprocessing* of reusable medical and surgical supplies. CAN/CSA-Z314.8-M88. Toronto: Canadian Standards Association, 1988:14.
- 124. Canadian Standards Association. Reprocessing of reusable medical and surgical supplies. CAN/CSA-Z314.8-M88. Toronto: Canadian Standards Association, 1988.
- 125. Sifontes JR, Block SS. Preservation of metals from microbial corrosion. In: Block SS, ed. Disinfection, sterilization, and preservation. 4th ed. Philadelphia: Lea & Febiger, 1991:948-74.
- 126. Spach DH, Silverstein FE, Stamm WE. *Transmission of infection by gastrointestinal endoscopy and bronchoscopy*. Ann Intern Med 1993;118:117-28.
- 127. Jarvis WR. Outbreaks associated with reprocessed medical devices: the hospital infections program, Centers for Disease Control and Prevention experience, January 1986-April 1996. In: Rutala WA, ed. Disinfection, sterilization and antisepsis in health care. Washington, D.C.: Association for Professionals in Infection Control and Epidemiology, Inc. and Polyscience Publications, Inc., 1998:17-23.
- 128. Canadian General Standards Board. Assessment of efficacy of antimicrobial agents for use on environmental surfaces and medical devices. Ottawa: Canadian General Standards Board, 1997.
- 129. Springthorpe VS, Sattar SA. *Chemical disinfection* of virus-contaminated surfaces. Critical Reviews in Environmental Control 1990;20:169-229.
- 130. Pelke S, Ching D, Easa D et al. *Gowning does not* affect colonization or infection rates in a neonatal intensive care unit. Arch Pediatr Adolesc Med 1994;148:1016-20.

- 131. Rutala WA, Weber DJ. Uses of inorganic hypochlorite (bleach) in health-care facilities. Clin Microbiol Rev 1997;10:597-610.
- 132. Sattar SA, Taylor YE, Paquette M, Rubino J. In-hospital evaluation of 7.5% hydrogen peroxide as a disinfectant for flexible endoscopes. Can J Infect Control 1996;11:51-54.
- 133. Prince DL, Prince HN, Thraenhart O et al. Methodological approaches to disinfection of human Hepatitis B virus. J Clin Microbiol 1993;31:3296-304.
- 134. Health Canada. Advisory notice: infection control for Creutzfeldt-Jakob disease. CCDR 1996;22: 147-48.
- 135. Health Canada. Infection control guidelines for health care workers for Creutzfeldt-Jakob disease in Canada. CCDR 1999. In press.
- 136. Kostenbauder HB. *Physical factors influencing the activity of antimicrobial agents*. In: Block SS, ed. *Disinfection, sterilization, and preservation.* 4th ed. Philadelphia: Lea & Febiger, 1991:59-71.
- 137. Health Canada. Drugs directorate guidelines disinfectant drugs. Ottawa, 1994:1-20.
- 138. Keene JH. Sterilization and pasteurization. In: Mayhall CG, ed. Hospital epidemiology and infection control. Baltimore: Williams & Wilkins, 1996:937-46.
- Rutala WA, Shafer KM. General information on cleaning, disinfection, and sterilization. In: Olmsted RN, ed. APIC infection control and applied epidemiology principles and practice. St. Louis: Mosby, 1996:Chapter 15.
- 140. Health Canada. *Guidelines for preventing the transmission of tuberculosis in Canadian health care facilities and other institutional settings.* CCDR 1996;22S1:1-50.
- 141. Dooley SW, Jarvis WR, Snider DE.
   Mycobacterium tuberculosis. In: Mayhall CG, ed.
   Hospital epidemiology and infection control.
   Baltimore: Williams & Wilkins, 1996:1200-23.
- 142. Smith PW, Roccaforte JS. Epidemiology and prevention of infections in home health care. In: Mayhall CG, ed. Hospital epidemiology and infection control. Baltimore, MD: Williams & Wilkins, 1996:1171-75.

- 143. Garofalo K. Home health. In: Olmsted RN, ed. APIC infection control and applied epidemiology principles and practice. St. Louis: Mosby, 1996:Chapter 90.
- 144. Perkins JJ. *Principles and methods of sterilization in health sciences*. 2nd ed. Vol. 1. Springfield: Charles C Thomas, 1969.
- 145. Canadian Standards Association. *Recommended* standard practices for emergency (flash) sterilization. CAN/CSA-Z314.13-M92. Toronto: Canadian Standards Association; 1992.
- 146. Association for the Advancement of Medical Instrumentation. AAMI – Good hospital practice: guidelines for the selection and use of reusable rigid sterilization container systems (ST33). Arlington, VA: AAMI Steam Sterilization Hospital Practices Working Group of the Thermal Sterilization Subcommittee, AAMI Sterilization Standards Committee, 1996.
- 147. Association for the Advancement of Medical Instrumentation. AAMI – Good hospital practice: flash sterilization – steam sterilization of patient care items for immediate use (ST37). Arlington, VA: AAMI Steam Sterilization Hospital Practices Working Group, AAMI Sterilization Standards Committee, 1996.
- 148. Herwaldt L, Smith S, Carter C. *Infection control in the outpatient setting*. Infect Control Hosp Epidemiol 1998;19:41-74.
- 149. Canadian Hospital Association, Environment Canada. *The elimination of CFCs in health care facilities*. CHA Press, Ottawa, 1994.
- 150. Najdovski L, Dragas AZ, Kotnik V. The killing activity of microwaves on some non-sporogenic and sporogenic medically important bacterial strains. J Hosp Infect 1991;19:239-47.
- 151. CHICA. Glass bead sterilizers: information review. CJIC 1994;9:123.
- 152. Ikarashi Y, Tsuchiya T, Nakamura A. *Cytotoxicity* of medical materials sterilized with vapour-phase hydrogen peroxide. Biomaterials 1995;16:177-83.
- 153. Gröschel DHM. Emerging technologies for disinfection and sterilization. In: Rutala WA, ed. Chemical germicide in health care: international symposium, May 1994. 1st ed. Washington, DC: Association for Professionals in Infection Control and Epidemiology, Inc, 1995:73-81.

- 154. Bond W. *Biological indicators for a liquid chemical sterilizer: a solution to the instrument reprocessing problem*? Infect Control Hosp Epidemiol 1993;14:309-12.
- 155. Proietti RM. Sterilization process monitoring: chemical indicators. In: Reichert M, Young JH, eds. Sterilization technology for the health care facility. 2nd ed. Gaithersburg, Maryland: Aspen Publishers, Inc, 1997:104-09.
- 156. Berube R, Oxborrow GS. Sterilization process monitoring: biological indicators. In: Reichert M, Young JH, eds. Sterilization technology for the health care facility. 2nd ed. Gaithersburg, Maryland: Aspen Publishers, Inc, 1997:110-15.
- 157. Rutala WA, Jones SM, Weber DJ. Comparison of a rapid readout biological indicator for steam sterilization with four conventional biological indicators and five chemical indicators. Infect Control Hosp Epidemiol 1996;17:423-28.
- 158. Rutala WA, Weber DJ. Use of chemical germicides in the United States: 1994 and beyond. In: Rutala WA, ed. Chemical germicides in health care: international symposium 1994. 1st ed. Washington, DC: Association for Professionals in Infection Control and Epidemiology, Inc, 1995:14-15.
- 159. Harris RW, Kehrer AF, Isacson P. *Relationship* of occupation to risk of clinical mumps in adults. Am J Epidemiol 1968;89:264-70.
- Rutala WA. Disinfection, sterilization, and waste disposal. 2nd ed. Baltimore: Williams & Wilkins, 1993:482.
- 161. Ford JE, Marshall VME, Reiter B. *Influence of the heat treatment of human milk on some of its protective constituents.* J Pediatr 1977;90:29-35.
- 162. Canadian Healthcare Association. *The reuse of* single-use medical devices: guidelines for healthcare facilities. Ottawa: CHA Press, 1996.
- 163. Maki DG, Botticelli JT, LeRoy ML et al. Prospective study of replacing administration sets for intravenous therapy at 48- vs 72-hour intervals: 72 hours is safe and cost-effective. JAMA 1987;258:1777-81.
- 164. Gordon SM, Tipple M, Bland LA et al. *Pyrogen* reactions associated with the reuse of disposable hollow fibre hemodialyzers. JAMA 1988;260:2077-81.

- 165. Nelson EJ, Ryan KJ. A new use for pasteurization: disinfection of inhalation therapy equipment. Respiratory Care 1971;16:97-103.
- 166. Craig DB, Cowan SA, Forsyth W et al. Disinfection of anesthesia equipment by a mechanical pasteurization method. Can Anaesth Soc J 1975;22:219-23.
- 167. Chatburn RL. *Decontamination of respiratory care equipment: what can be done, what should be done.* Respiratory Care 1989;34:98-110.
- 168. Keroack MA, Rosen-Kotilainen H. Microbiology/ laboratory diagnostics. In: Olmsted RN, ed. APIC infection control and applied epidemiology principles and practice. St. Louis: Mosby, 1996:Chapter 7.
- 169. Health Canada. Infection control guidelines for long-term care facilities. Ottawa: Minister of National Health and Welfare, 1994. (Supply and Services Canada, Cat. No. H30-11-6-6-1994E).
- 170. Favero MS, Alter MJ, Bland LA. Nosocomial infections associated with hemodialysis. In: Mayhall CG, ed. Hospital epidemiology and infection control. Baltimore: Williams & Wilkins, 1996:693-714.
- 171. Favero MS, Bond WW. Sterilization, disinfection, and antisepsis in the hospital. In: Balows A, Hausler Jr WJ, Herrmann KL, et al., eds. Manual of clinical microbiology. 5th ed. Washington: American Society of Microbiology, 1991:183-200.
- 172. Martin MA. Nosocomial infections related to patient care support services: dietetic services, central services department, laundry, respiratory care, dialysis, and endoscopy. In: Wenzel RP, ed. Prevention and control of nosocomial infections. 3rd ed. Baltimore: Williams & Wilkins, 1997:647-88.
- 173. Weber DJ, Rutala WA. Environmental issues and nosocomial infections. In: Wenzel RP, ed. Prevention and control of nosocomial infections. 3rd ed. Baltimore: Williams & Wilkins, 1997:491-514.
- 174. Canadian Standards Association. Water treatment equipment and water quality requirements for

*haemodialysis*. Z364.2.2-94. Toronto: Canadian Standards Association, 1994.

- 175. Canadian Standards Association. Fluid supply and monitoring systems for haemodialysis. Z364.2.1-94. Toronto: Canadian Standards Association, 1994.
- 176. Favero MS, Petersen NJ. Microbiologic guidelines for hemodialysis systems. Dial Transplant 1977;6:34-6.
- 177. Association for the Advancement of Medical Instrumentation. *American national standard for hemodialysis systems*. ANSI/AAMI RD5-1992 1992.
- 178. Bland LA, Favero MS. *Microbiological and endotoxin considerations in hemodialyzer reprocessing*. AAMI Standards and Recommended Practices 1993;3:293-300.
- 179. Favero MS, Bland LA. *Microbiologic principles applied to reprocessing hemodialyzers*. In: Deane N, Wineman RJ, Bemis JA, eds. *Guide to reprocesssing of hemodialyzers*. Boston: Martinus Nijhoff, 1986:63-73.
- Collins BJ. *The hospital environment: how clean should a hospital be?* J Hosp Infect 1988;11 (Supp. A):53-6.
- 181. Chou T. Environmental services. In: Olmsted RN, ed. APIC: infection control and applied epidemiology principles and practice. St. Louis: Mosby, 1996:107-7.
- 182. Ward RL, Bernstein DI, Knowlton DR et al. Prevention of surface-to-human transmission of rotaviruses by treatment with disinfectant spray. J Clin Microbiol 1991;29:1991-96.
- 183. Lior L, Litt M, Hockin J et al. Vancomycinresistant Enterococci on a renal ward in an Ontario hospital. CCDR 1996;22:125-28.
- 184. Rosenberg J. *Methicillin-resistant* Staphylococcus aureus (MRSA) in the community: who's watching? Lancet 1995;346:132-33.
- 185. Patterson JE, Sanchez RO, Hernandex J et al. Special organism isolation: attempting to bridge the gap. Infect Control Hosp Epidemiol 1994;15:335-38.

- 186. Health Canada. *Controlling antimicrobial resistance: an integrated action plan for Canadians.* CCDR 1997;23S7:1-32.
- 187. Mbithi JN, Springthorpe VS, Sattar SA et al. Bactericidal, virucidal, mycobactericidal activities of reused alkaline glutaraldehyde in an endoscopy unit. J Clin Microbiol 1993;31:2988-95.
- Health Canada. *Laboratory biosafety guidelines*.
   2nd ed. Ottawa: Health Canada, 1996. (Supply and Services Canada, Cat. No. MR21-1/1996E.)
- 189. CDC. 1988 agent summary statement for human immunodeficiency virus and report on laboratoryacquired infection with human immunodeficiency virus. MMWR 1988;37:S1-22.
- 190. AORN. Recommended practices: sanitation in the surgical practice setting. AORN 1992;56:1089-95.
- 191. Operating Room Nurses Association of Canada. *Recommended standards for perioperative nursing practice* (1-134).
- 192. AORN. Preoperative preparation of the environment phase. In: Recommended standards for perioperative nursing practice. 1993:30-1.
- 193. Pugliese G, Huntstiger CA. *Central services, linens and laundry*. In: Bennett JV, Brachman PS, eds. *Hospital infections*. 3rd ed. Toronto: Little Brown and Co., 1992:335-44.
- 194. Tompkins DS, Johnson P, Fittall BR. Lowtemperature washing of patients' clothing; effects of detergent with disinfectant and a tunnel drier on bacterial survival. J Hosp Infect 1988;12:51-8.
- 195. Weinstein SA, Gantz NM, Pelletier C et al. Bacterial surface contamination of patients' linen: Isolation precautions versus standard care. Am J Infect Control 1989;17:264-67.
- 196. Mulhausen P. Infection and control of nosocomial infection in extended care facilities. In: Wenzel RP, ed. Prevention and control of nosocomial infections. 3rd ed. Baltimore: Williams & Wilkins, 1997:283-306.
- 197. Degelau J. *Scabies in long-term care facilities*. Infect Control Hosp Epidemiol 1992;13:421-25.

- 198. Haag ML, Brozena SJ. Attack of the scabies: what to do when an outbreak occurs. Geriatrics 1993;48:45-53.
- 199. Sargent SJ. Ectoparasites. In: Mayhall CG, ed. Hospital epidemiology and infection control. Baltimore: Williams & Wilkins, 1996:465-72.
- 200. Letau LA. Nosocomial transmission and infection control aspects of parasitic and ectoparasitic diseases Part III. Ectoparasites/summary and conclusions. Infect Control Hosp Epidemiol 1991;12:179-85.
- 201. Pien FD. Ectoparasites. In: Olmsted RN, ed. APIC infection control and applied epidemiology principles and practice. St. Louis: Mosby, 1996:Chapter 55.
- 202. Maki DG, Alvarado C, Hassemer C. *Double*bagging of items from isolation rooms is unnecesary as an infection control measure: a comparative study of surface contamination with single- and double-bagging. Infect Control 1986;7:535-37.
- 203. Health Canada. *Canadian contingency plan for viral hemorrhagic fevers and other related diseases.* CCDR 1997;23S1:1-13.
- 204. Centers for Disease Control and Prevention. Management of patients with suspected viral hemorrhagic fever. MMWR 1988;37:1-15.
- 205. Joint Committee on Healthcare Laundry Guidelines. *Guidelines for healthcare linen service* -1994. P.O. Box 1283, Hallandale, Florida 33008: The Joint Committee on Healthcare Laundry Guidelines, 1994.
- 206. Health Canada. Laundry/linen services for healthrelated facilities. Minister of Supply and Services, 1994. (Cat. No. H39-304/1994E).
- 207. Martin MA. Nosocomial infections related to patient care support services: dietetic services, central services department, laundry, respiratory care, dialysis and endoscopy. In: Wenzel RP, ed. Prevention and control of nosocomial infections. 2nd ed. Baltimore: Williams and Wilkins, 1993:101-03.
- 208. Reinhardt PA, Gordon JG, Alvarado CJ. *Medical* waste management. In: Mayhall CG, ed. *Hospital*

*epidemiology and infection control.* Baltimore: Williams & Wilkins, 1996:1099-108.

- 209. Schmidt EA. *Medical waste management*. In: Olmsted RN, ed. *APIC infection control and applied epidemiology principles and practice*. St. Louis: Mosby, 1996:Chapter 112.
- 210. Canadian Standards Association. Guidelines for the management of biomedical waste in Canada. Under the direction of the Canadian Council of Ministers of the Environment (CCME), 1992.
- 211. Canadian Standards Association. Handling of waste materials within health care facilities. CAN/CSA-Z317.10-88. Toronto: Canadian Standards Association, 1988.
- 212. *Health officials ask Morton medical waste facility to close temporarily*. News Release 98-25. Washington State Department of Health, March 4, 1998.
- 213. Rutala WA. Disinfection, sterilization, and waste disposal. In: Wenzel RP, ed. Prevention and control of nosocomial infections. Baltimore: Williams & Wilkins, 1997:577.
- Rutala WA, Webber DJ. Infectious waste mismatch between science and policy. N Engl J Med 1991;325:578-82.
- 215. Wade BH. Outpatient/out of hospital care issues. In: Wenzel RP, ed. Prevention and control of nosocomial infections. 3rd ed. Baltimore: Williams & Wilkins, 1997:243-59.
- 216. Transport Canada. *Transportation of dangerous goods act, 1992*. Amendment, schedule no. 16, 24 March 1994. Can Gazette 1994;128:1526-35. (Part II).
- 217. Turnberg WL, Lowen LD. *Home syringe disposal:* practice and policy in Washington State. Diabetes Educator 1994;20:489-92.
- 218. Liss GM, Crimi C, Jaczek K et al. *Improper* office disposal of needles and other sharps: an occupational hazard outside of health care institutions. Can J Public Health 1990;81:417-20.
- 219. Burke EL. A survey of recent literature on medical waste. JEH 1994;56:11-14.

- 220. Rutala WA, Mayhall CG. *SHEA position paper: medical waste.* Infect Control Hosp Epidemiol 1992;13:38-48.
- 221. Daschner MD. *The hospital and pollution: role* of the hospital epidemiologist in protecting the environment. In: Wenzel RP, ed. *Prevention and* control of nosocomial infections. 3rd ed. Baltimore: Williams & Wilkins, 1997:595-605.
- 222. Escaf M, Shurtleff S. A program for reducing biomedical waste: the Wellesley Hospital experience. CJIC 1996;11:7-11.
- 223. MacPherson DW. *Evidence-based medicine*. CCDR 1994;20:145-56.

# Appendix 1 Glossary

**Antimicrobial agent:** a product that kills or suppresses the growth of microorganisms.

**Antiseptics:** chemicals that kill microorganisms on living skin or mucous membranes. Antiseptics should not be used in housekeeping.

**Biofilm:** the process of irreversible adhesion initiated by the binding of bacteria to the surface by means of exopolysaccharide material (glycocalyx). The development of adherent microcolonies leads eventually to the production of a continuous biofilm on the colonized surface. Bacteria within biofilms tend to be more resistant to antibiotics and biocides than cells in batchtype culture.

**Biomedical waste:** defined by the CSA<sup>(210)</sup> as waste that is generated by human or animal health care facilities, medical or veterinary settings, health care teaching establishments, laboratories, and facilities involved in the production of vaccines.

**Cleaning:** the physical removal of foreign material, e.g., dust, soil, organic material such as blood, secretions, excretions and microorganisms. Cleaning physically removes rather than kills microorganisms. It is accomplished with water, detergents and mechanical action. The terms "decontamination" and "sanitation" may be used for this process in certain settings, e.g., central service or dietetics. Cleaning reduces or eliminates the reservoirs of potential pathogenic organisms. Cleaning agents are the most common chemicals used in housekeeping activity.

**Critical items:** instruments and devices that enter sterile tissues, including the vascular system. Critical items present a high risk of infection if the item is contaminated with any microorganisms, including bacterial spores. Reprocessing critical items involves meticulous cleaning followed by sterilization.

**Decontamination:** the removal of disease-producing microorganisms to leave an item safe for further handling.

**Disinfection:** the inactivation of disease-producing microorganisms. Disinfection does not destroy bacterial spores. Disinfectants are used on inanimate objects; antiseptics are used on living tissue. Disinfection usually involves chemicals, heat or ultraviolet light. Levels of chemical disinfection vary with the type of product used.

**Fomites:** those objects in the inanimate environment that may become contaminated with microorganisms and serve as a vehicle of transmission<sup>(115)</sup>.

**Germicide:** an agent that destroys microorganisms, especially pathogenic organisms.

**Hand wash(ing):** a process for the removal of soil and transient microorganisms from the hands.

**Hand antisepsis:** a process for the removal or destruction of resident and transient microorganisms on hands.

**Heavy microbial soiling:** the presence of infection or high levels of contamination with organic material, e.g., infected wounds, feces.

**High level disinfection:** level of disinfection required when processing semicritical items. High level disinfection processes destroy vegetative bacteria, mycobacteria, fungi and enveloped (lipid) and non enveloped (non lipid) viruses, but not necessarily bacterial spores. High level disinfectant chemicals (also called chemisterilants) must be capable of sterilization when contact time is extended. Items must be thoroughly cleaned prior to high level disinfection.

**Infectious waste:** that portion of biomedical waste that is capable of producing infectious disease<sup>(219)</sup>.

**Intermediate level disinfection:** level of disinfection required for some semicritical items. Intermediate level disinfectants kill vegetative bacteria, most viruses and most fungi but not resistant bacterial spores.

Low level disinfection: level of disinfection required when processing noncritical items or some environmental surfaces. Low level disinfectants kill most vegetative bacteria and some fungi as well as enveloped (lipid) viruses (e.g., hepatitis B, C, Hantavirus, and HIV). Low level disinfectants do not kill mycobacteria or bacterial spores. Low level disinfectants-detergents are used to clean environmental surfaces.

**Noncritical items:** those that either touch only intact skin but not mucous membranes or do not directly touch the patient. Reprocessing of noncritical items involves cleaning and/or low level disinfection.

**Plain or nonantimicrobial soap:** detergent-based cleansers in any form (bar, liquid, leaflet, or powder) used for the primary purpose of physical removal of soil and contaminating microorganisms. Such soaps work principally by mechanical action and have weak or no bactericidal activity. Although some soaps contain low concentrations of antimicrobial ingredients, these are used as preservatives and have minimal effect on colonizing flora.

**Sanitation:** a process that reduces microorganisms on an inanimate object to a safe level (e.g., dishes and eating utensils are sanitized).

**Semicritical items:** devices that come in contact with nonintact skin or mucous membranes but ordinarily do not penetrate them. Reprocessing semicritical items involves meticulous cleaning followed preferably by high-level disinfection (level of disinfection required is dependent on the item, see Table 5). Depending on the type of item and its intended use, intermediate level disinfection may be acceptable (see Table 5 for examples).

**Sharps:** needles, syringes, blades, laboratory glass or other objects capable of causing punctures or cuts.

**Sterilization:** the destruction of all forms of microbial life including bacteria, viruses, spores and fungi. Items must be cleaned thoroughly before effective sterilization can take place.

# Appendix 2 Guideline Rating System

The Laboratory Centre for Disease Control (LCDC) Infection Control Guidelines previously used a system for rating guideline statements based on the strength of the evidence<sup>(15,71)</sup>. A more elaborate system of rating has recently been proposed<sup>(223)</sup>, with five categories to rank the strength of the evidence *for* (categories A-C) or *against* (D-E) a statement, and three grades to describe the quality of supportive studies. This system of rating follows the guidelines that have been recently published for clinical practice guidelines. The format uses an evidence-based medicine approach, which stresses the examination of evidence from clinical research, especially randomized studies, and places less emphasis on intuition and recalled experiences.

This new rating scheme, with one modification, is used in this document with appropriate clarification of

evidence described in the text. The modification occurs in Category C with the word "insufficient" replacing "poor" in the original rating scheme. This system is outlined in Table 11.

The information in these guidelines was current at the time of publication; it should be emphasized that areas of knowledge and aspects of medical technology advance with time. <u>Guidelines, by definition, are directing</u> principles and indications or outlines of policy or conduct, which should not be regarded as rigid standards. These guidelines should facilitate development of standards but respect the autonomy of organizations and recognize their governing body's authority and responsibility to ensure the quality of care provided by the institution.

## Table 11: Strength and Quality of Evidence for Recommendations

Categories for st	Categories for strength of each recommendation		
Category	Definition		
A	Good evidence to support a recommendation for use.		
В	Moderate evidence to support a recommendation for use.		
С	Insufficient evidence to support a recommendation for or against use.		
D	Moderate evidence to support a recommendation against use.		
E	Good evidence to support a recommendation against use.		
Categories for q	Categories for quality of evidence on which recommendations are made		
Grade	Definition		
Ι	Evidence from at least one properly randomized, controlled trial.		
Ш	Evidence from at least one well-designed clinical trial without randomization, from cohort or case-controlled analytic studies, preferably from more than one centre, from multiple time series, or from dramatic results in uncontrolled experiments.		
Ш	Evidence from opinions of respected authorities on the basis of clinical experience, descriptive studies, or reports of expert committees.		

# Appendix 3 Drugs Directorate Guidelines

For more information regarding disinfectants and for an order form for publications of the Drugs Directorate, including the Drugs Directorate Guidelines, visit the website at the following address: www.hc-sc.gc.ca/hpb-dgps/therapeut For further information from the Therapeutics Products Programme, Bureau of Pharmaceutical Assessment, Health Protection Branch, Health Canada, telephone (613) 965-6466 and (613) 954-6503.